Air Revitalizer

INSTRUCTION MANUAL



Model NO. #75616 AC120V 60Hz 13W


Please read all instructions carefully.

IMPORTANT

Please read all instructions carefully before use.

- 1. Place it on a secure and level area. Keep out of reach of children to prevent any accident.
- 2. Keep water level half of the container.
- 3. Add the recommended air revitalizing concentrate about two to four drops into the water.
- 4. It must be changed every 3 -4 days or once a week
- 5. Empty water from the container and clean it with dry cloth, place and keep it in the box when not using it.
- 6. Always disconnect main-cord from electrical outlet before removing TOP COVER or when the equipment is not in use.
- 7. Do not submerge the TOP COVER into water or wash under a running tap. Use only a damp cloth or sponge to clean.
- 8. Do not use any chemicals to clean the equipment, always use tap water only.
- 9. Do not over fill the water container. Keep the water below the MAXIMUM line.
- 10. In case of damaged main cord. DO NOT USE this equipment and must refer to your service agent immediately.
- 11. The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 12. Young children should be supervised to ensure that they do not play with the appliance.

This is how Air Revitalizer works



DIRECTION OF USE



(1) Remove TOP-COVER




(2) Fill water container with clean tap water up to the MAXIMUM line




(3) Add recommended amount of air revitalizing concentrate into the water



(4) Replace TOP-COVER Make sure TOP-COVER is securely seated on the water container







(6)Turn on the power switch and light color switch. Use the 2 position light switch to either cycle through the colours or keep a single colour.