


ARCH BOW TOP LP101

ESDXL21PT027



Assembly Instructions

For assistance please contact
customer care on
01636821215

Mercia Garden Products Ltd
Old Great North Road
Sutton on Trent
Newark
Nottinghamshire
NG23 6QN

www.merciagardenproducts.co.uk

ASSEMBLY INSTRUCTIONS





ESDXL21PT027

Before assembly.





- We recommend that time is taken to read the instructions before starting assembly, then follow the easy step by step guide. The instruction sheet is only a guide to the assembly. Certain items may not be shown to scale.
- Check all components prior to assembly.
- Drill all screw locations where indicated.
- This product should be assembled by no fewer than two people.
- Never attempt to erect the assembly in high winds.

Recommended tools for assembly:

- Drill with 3 mm diameter drill bit
- Cross-head screwdriver
- Step ladder



70 mm screws



Fixing kit	Qty
70 mm screws *	8
50 mm screws *	18

* Drilling the pilot holes is necessary