

# Assembly Instruction Sheet for Model HL796248


## Package Contents

Part	Description	Quantity
A	Mounting Bracket	1 pc.
B	Fixture Body	1 pc.
C	Remote Control	1 pc.



A



B



C



### STEP 1

Mark the drilling position on ceiling with the help of the Mounting Bracket(A).  
Drill holes on the marks and stick the expansion anchors into the holes.  
Fix the Mounting Bracket(A) to the expansion anchors with self-tapping screws.

### STEP 2

Hold the fixture close to the ceiling.  
Connect live line to wire color Black/Red from the canopy of Fixture Body(B) according to the wiring diagram.  
Connect neutral line to wire color White/Blue from the canopy of Fixture Body(B) according to the wiring diagram.

### STEP 3

Attach the canopy of Fixture Body(B) to the Mounting Bracket(A).

Your fixture is now assembled and ready to use.