




STEP 3



Remove the fabric corner of canopy and release the Corner Ribs out of the top corner bracket by snapping the pin.  
Untie all velcros around side cross braces, make sure they are cleared for collapsing.  
Store this gazebo in roller bag provided


TAKE DOWN

STEP 1



Remove stakes from the ground, raise and tilt the leg off the ground, then press snap button to slide back the lower pole all the way to the bottom end and release the button. Repeat until all four legs have been lowered.

STEP 2



Press the button on the locking slider at the corner bracket to disengage the frame and allow it to collapse. Lift the frame off the ground and slowly walk towards partner being careful not to pinch fingers.