


INSTALLATION INSTRUCTIONS

DeerValley®

Wall-Mounted Bathroom Sink with Storage Rack





Prior to Installation:

- Please read all instructions carefully before beginning installation.
- Verify that all parts are included and free from damage before proceeding.
- Shut off the water supply before starting any plumbing work.
- Use appropriate safety equipment when handling tools.
- Installation is recommended to be performed by a qualified professional if you are not familiar with plumbing or wall-mounted installations.
- This sink is designed for installation on solid walls. Additional wall reinforcement may be required for drywall or plaster walls.
- Handle the ceramic basin with care when placing it onto the storage rack to avoid chipping, cracking, or misalignment.
- Do not overtighten fittings, as this may cause damage to the product or connections.
- Do not place heavy objects on the sink or storage rack during installation.
- Clean the sink regularly using mild, non-abrasive cleaners to maintain its finish.

**If you have any questions or concerns
please contact us:**

(312) 626-9466
service@deervalleybath.com

1. Recommended Tools (Not Included)



Gloves




Safety Glasses



Pencil or Marker



Measuring Tape




Phillips screwdriver



Electric Drill




Rubber Mallet




Level

- Note: The tools listed are recommendations only and may vary depending on the specific installation requirements.


2. Package Contents



Sink × 1



Frame × 2



Rod × 6




Long Screw × 4
Short Screw × 6
Wall Anchor × 4
Plastic Washer × 10
Decorative Cap × 10



Foam Double-Sided
Tape Piece × 4


Note: Drawings are for reference only. Please refer to the actual product.

3. Installation Instructions




Step 1

Insert three rods (open on both ends) into the three center holes of one frame.




Step 2

Insert two rods (with threaded holes on both ends) into the outer holes of the same Frame.



Step 3


Install the upper thicker rod, then align and attach the second frame onto all rods.



Step 4


Insert four short screws through plastic washers, then tighten them into the frame to secure the rods.
Snap decorative caps onto the screws.

Note: Drawings are for reference only. Please refer to the actual product.




Step 5

Repeat Step 4 to secure the upper rod.




Step 6

The storage rack assembly is now complete.



Step 7


Position the assembled rack against the wall and use it as a template to mark the mounting hole locations.




Step 8

Confirm the four marked drilling points are level and properly aligned.


Note: Drawings are for reference only. Please refer to the actual product.




Step 9
Drill holes at the marked locations.



Step 10
Insert the wall anchors into the drilled holes.




Step 11
Insert four long screws through plastic washers, then tighten them into the rack to secure it to the wall. Snap decorative caps onto the screws.



Step 12
Apply the foam double-sided tape pieces to the four corners of the rack.

Note: Drawings are for reference only. Please refer to the actual product.



Step 13

Carefully place the sink onto the rack.

Note: Drawings are for reference only. Please refer to the actual product.

4.Care & Maintenance

To keep your wall-mounted sink and storage rack looking their best, clean them regularly using a soft cloth and a non-abrasive cleaner. Always rinse thoroughly and wipe dry after cleaning to prevent water spots, mineral buildup, and surface damage.

What to Do



- Rinse off cleaning residue thoroughly to prevent buildup.
- Wipe the sink and rack dry with a soft cloth after each use.
- Use baking soda or a mild detergent for tough stains.
- Test any new cleaner on a small, hidden area before full use.
- Use a drain strainer to catch hair or small items and help prevent clogs.

What to Avoid



- Do not use abrasive cleaners, scouring pads, or steel wool.
- Do not allow bleach, acids, or harsh chemicals to contact the sink or rack.
- Do not let metal or sharp objects scrape or impact the sink surface.
- Do not leave standing water or stain-prone liquids in the sink for extended periods.
- Do not overload the storage rack or hang excessive weight from it.

LIMITED WARRANTY COVERAGE

1-YEAR LIMITED WARRANTY

DeerValley products are made with quality materials and excellent craftsmanship to provide customers with a long-lasting product. If any defects in materials or craftsmanship are found under normal use within the first year of delivery, DeerValley will provide replacement parts at no charge or, at its option, replace any product or part of the product deemed defective under normal installation, use, service, and maintenance. This warranty applies only to the original purchaser. Proof of purchase will be required to process any claims. **SCRATCHES ARE NOT COVERED UNDER WARRANTY.**

The manufacturer warrants that this product will be free from manufacturing defects for the duration of the above-mentioned warranty period. Please retain a copy of the original invoice as proof of purchase.

DeerValley will, at its option, (1) repair or replace the defective part(s) or product(s) at no charge; (2) issue a refund for the original purchase price of the product(s) (valid within 30 days from the date of delivery); or (3) issue a credit to be applied toward the purchase of a new DeerValley product. Shipping/delivery charges may apply and are at DeerValley's sole discretion.

DeerValley recommends that installations be performed by a licensed, professional plumber. DeerValley will not be held responsible for any damage or product failure resulting from improper installation, misuse, or failure to hire a licensed professional. Additionally, DeerValley is not responsible for any removal or installation costs.

This limited warranty does not cover goods that have been subjected to accidents, negligence, improper installation, product abuse, product misuse, or the use of cleaners containing abrasives, alcohol, or other organic solvents. Such exclusions apply regardless of whether the actions were performed by a contractor, service company, or the purchaser.

DeerValley's responsibility under this limited warranty is limited solely to the replacement of parts and does not cover any other costs. DeerValley will not be responsible for labor charges or any damage incurred during installation, repair, or replacement, nor for any indirect, incidental, or consequential damages, losses, injuries, or costs of any kind related to this product. Except as required by law, this limited warranty replaces and excludes all other warranties, conditions, and guarantees, whether expressed or implied, statutory or otherwise, including but not limited to those regarding merchantability or fitness for a particular purpose.

RESPONSIBILITIES OF OTHERS

It is the responsibility of the installer or building contractor, acting on behalf of the user, to inspect the unit prior to installation. They are responsible for ensuring that the unit is free from defects or damage.

Notices are placed on and within the unit, as well as on the shipping carton, to inform the installer of their responsibility.

If a problem is identified, the unit must not be installed. DeerValley is not responsible for failures or damage that could have been identified, repaired, or prevented through proper inspection and testing prior to installation.

Damage occurring during transit is the responsibility of the carrier. The user or installer must open the crate and inspect the unit for damage upon delivery. If damage is discovered, it must be reported immediately to the seller and the carrier in writing, and an inspection must be requested. If the carrier fails to respond, the issue should be reported to both the seller and the carrier. Freight claims should be filed promptly thereafter.

LIMITATIONS AND EXCLUSIONS

This warranty does not cover negligence, misuse, abuse, improper installation, carelessness, accidents, hard water or mineral deposits, exposure to corrosive materials, misapplication, damages resulting from improper maintenance, alteration of the product, or failure to follow the care or installation instructions provided with your product. The warranty becomes void if the DeerValley product is altered or if repairs are attempted using unauthorized accessories or parts not provided by DeerValley.

DeerValley is not liable for the loss of use of its products, inconvenience, or any other incidental or consequential costs, expenses, or damages. Please note that some states do not allow the exclusion or limitation of incidental damages.

DISCLAIMER

Except as expressly stated, no warranties or obligations, whether express, implied, oral, or statutory, are provided. No dealer or other individual has the authority to make any warranties or representations regarding DeerValley or its products. DeerValley shall not be held responsible for any such unauthorized warranties or representations.

WARRANTY SERVICE

NOTE: When requesting warranty service, please ensure you have the following:

- A copy of the original invoice
- Date of installation
- Description and pictures of the defect
- Model number or product description

To obtain warranty service or replacement parts, contact DeerValley Customer Service. DeerValley will determine whether to repair or replace the product, issue a refund, or provide a credit.