












Assembly Instructions







Accessories

1-Left Side Panel	1PC	2-Right Side Panel	1PC
			
3-Cross Leg	2PCS	4-Middle Frame	1PC
			
5-Back Panel	2PCS	6-Left Bottom Panel	1PC
			

7-Right Bottom Panel	1PC	8-Top Panel	1PC
			
9-Shelf	4PCS	10-Left Door	1PC
			
11-Right Door	1PCS		
			

A * 32  M5*10MM	B * 4  M5	C * 2  M8 M5*30MM M5
D * 12 	E * 2 	F * 2 
G * 2 	H * 4 	I * 2 
Spare  Already pre-installed on the doors	Foot*4  Already pre-installed on the cross legs 3	Key*2  Attached on the doors 10 and 11

Each lock has been pre-installed on each door, and the corresponding two keys are attached on each door.
The keys to each door are not universal. Please remove the keys from the doors, label and store them properly before assembling.



CAUTION

An assistant is required


CUSTOMER FIRST, SERVICE FOREMOST!

Questions? Issues?


CONTACT US

REPLY WITHIN 24 HOURS IN BUSINESS DAYS


Step 1: Put two cross legs 3 on a flat surface




Step 2: : Insert the cross legs 3 into the bottom of left side panel 1



Step 3: Insert the cross legs 3 into the bottom of right side panel 2



Step 4: Insert the cross legs 3 into the bottom of
of middle frame 4




A*6



M5*10MM

Step 5: Fix side panels 1, 2 and middle frame 4 with cross legs 3 by 6 screws A




A*8



M5*10MM

Step 6: Install one back panel 5, then fix it with left side panel 1 and middle frame 4 by 8 screws A




A*8




M5*10MM


Step 7: Install another back panel 5, then fix it with right side panel 2 and middle frame 4 by 8 screws A




Step 8: Tilt left bottom panel 6 into the cabinet
and put it on the left side of cross legs 3



Step 9: Tilt right bottom panel 7 into the cabinet and put it on the right side of cross legs 3



Step 10: Put top panel 8 on the top (Place the rear part of the top panel on the back panels first)




After the screws are tightened in the subsequent step, the top panel will be properly aligned

A*10



M5*10MM



Step 11: Push top panel 8 backward to the correct place, then fix it with other parts by 10 screws A



C*2		
		
M8	M5*30MM	M5

Step 12: Fix the cabinet on the wall with 2 expansion screws C to prevent tipping

If the ground is uneven, it can be adjusted by rotating the screw. This will fix the situation where the door is not easily opened or closed.



DANGER



Always secure this furniture with an anchor device.

Unsecured furniture can cause serious injury or death to children.

Never allow children to stand, climb or hang on drawers, doors or shelves.

Never open more than one drawer or door at a time.

Place the heavy items on the lower position.


Never place a television on this furniture.

This is a permanent label. Do not remove!


D*12




Step 13: Install 12 shelf clasps D on the side panels
(The height can be adjusted as your needs)




Step 14: Put four shelves 9 on the shelf clasps







E*2	F*2	Step 15: Insert the door pivots E into the hole of the bottom corners (0/1 shim F can be used to adjust the seam), then insert the doors 10 and 11 into the pivots at the bottom and adjust the spring shafts at the top corners
		



There are two holes here, and E should be inserted into the smaller hole.

B*4	G*2	H*4	Step 16: Install 2 handles G on the doors with 4 screws B, then install 4 magnets H on the doors as shown
			





Step 17: Insert both ends of the two hanging rods into the corresponding hanging pieces on the side panels

