
ASSEMBLY INSTRUCTION



+ Do Not Use | + Suggested Power Tools | Adults





NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

Part # - Sofa Base

Part # - leg

Part # - Middle leg

Do not assemble if any of the following

Hardware parts missing:

Part # - Allen Wrench

Part # - Bolt Part # - Washer

2 IMPORTANTASSEMBLY

INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Parts Included

1 SOFA BASE

1PC



(2) I FG 4PCS



③ MIDDLE LEG 1PCS



+ Hardware Included

A ALLEN WRENCH B BOLT

Ø5/16 *10cm 1PC

M8*70MM 4PCS



C WASHER M8*16MM 4PCS



ASSEMBLY INSTRUCTION

