# INSTALLATION

**CAUTION**

Parts are placed at the bottom of the product.

- If you have any questions with the product, please contact us





# Assembly Instructions

Your recliner comes in 3 packages, carefully remove all of components from the packaging and set aside for assembly.


**CAUTION:**

**DO NOT** use any sharp objects to open plastic wrapped components as damage to product or components may result.


## Package Contents.

| | | | | |
|---|---|---|---|---|
|  |  |  |  |  |
| **A 1* Chair Back** | **B 1* Chair Seat** | **C 1* Left Armrest** | **D 1* Right Armrest** | **E 1* Power Cord** |
|  |  |  |  |  |
| **G 1* Power cord** | **G 1* Power cord** | **H 1* Power Source** | **I 2 *SupportingFeet** | **J 4*SupportingFeet** |


**Step 1:** Find a small bag in the accessories box. Take out Supporting Feet(I) from the small bag. Assemble the two Supporting Feet as shown on the bottom of mechanism to avoid toppling and falling.




## Step 2





## Step 3






## Step 4




## Step 5










# Instructions of Connecting Power Cords

No. 1 and No.2 wires connect the backrest to the chair seat.
No.3 wire connects the backrest to the power cord(F).
No.4 wire connects up the backrest and massage remote(G).
No.5 wire connects the motor with the wire from left armrest, which has a control panel.
No.6 wire connects the motor to the power source(E).




**Note:**

1. The connection plugs have different colors, black to black, white to white, red to red.
2. Plug both the **Power Cord**(F) and **Power Source**(E) into outlet to get the recliner working.

# Warnings

1. Please check if the components of the chair are all included and can be used normally.
2. Assemble all components according to the instruction correctly before you connect the chair to the power.
3. Please DO NOT sit on the armrests or footrest to eliminate the risk of tipping over.
4. If the chair is damaged or doesn't match the website description, please send clear pictures of the product and label of the carton to our service team for further help.
5. If the recliner doesn't work, you may try the following measures for self-checking firstly:
   a) Check if all the cables are connected;
   b) Check if the light of transformer is on.

   If the chair still doesn't work, please feed the information back to our customer service in time and we'll help you solve the matter as soon as possible.
6. If you have any questions with the product, please contact us via Email (we will reply to you within 24 hours.







