

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum





Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening


 **SAFAVIEH**
O U T D O O R

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Leg		8X
B	Block		8X
C	Suppost		4X
D	Back frame		1X
E	Cross bar		4X
H	Cross bar -1		4X
H1	Cross bar -2		4X
H2	Cross bar -3		8X
H3	Screw -1	 M6X50	40X
H4	Screw -1	 M6X20	48X
H5	Allen bolt -1	 M8X30	16X
H6	Allen bolt -2	 M8X15	80X
H7	Allen bolt -3	 M6X40	4X
H8	Allen bolt - 4	 M6X20	36X
H9	Tandu - 1	 M6X15	96X
H10	Tandu - 1	 M8X15	36X

Model# PAT7019A

Product Dimensions:118" W x 118" D x 102" H



CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum

Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening


 **SAFAVIEH**
O U T D O O R

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
H11	Parth -L1		8X
H12	Parth - U		8X
H13	Washer-1		4X
H14	Washer-2		6X
H15	Parth key		8X
H16	Parth -L2		8X
H17	Cord		2X
H18	Cloth around		4X
H19	Fabric roof		1X
H20	whether mound		1X
H21	Parth -L3		8X
H22	Allen key		4X

Model# PAT7019A

Product Dimensions:118" W x 118" D x 102" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes.

Tools Required for Assembly (included): Allen Key

1



Step 1


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes.


Tools Required for Assembly (included): Allen Key

2



Step 2

3



Step 3


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes.


Tools Required for Assembly (included): Allen Key

2



Step 4

3



Step 5


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes.


Tools Required for Assembly (included): Allen Key

6




Step 6

7



Step 7

8



Step 8


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes.


Tools Required for Assembly (included): Allen Key

8



Step 8

9



Step 9

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 30 minutes.

Tools Required for Assembly (included): Allen Key

11

12

1408804



Step 11