

DINING CHAIR
WITH CUSHION SEAT

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION


A UPPER LEG FRAME

1 PC




B LOWER LEG FRAME

1 PC



C SEAT AND BACK

1 PC



D CORNER BLOCK


2 PCS



HARDWARE IDENTIFICATION


1 ALLEN HEAD SCREW

1 PC




2 BOLT

4 PCS




3 SCREW

8 PCS



4 ALLEN WRENCH


1 PC




NOTE : QUANTITIES SHOWN ARE FOR ONE CHAIR.

NOTE : PHILLIPS HEAD SCREW DRIVER IS REQUIRED IN THE ASSEMBLY PROCESS. HOWEVER, MANUFACTURER DOES NOT PROVIDE THIS ITEM.


STEP 1




STEP 2



STEP 3



STEP 4



STEP 5

