



ROUND ACCENT TABLE

ASSEMBLY INSTRUCTIONS



IF PARTS ARE MISSING OR DAMAGED, DO NOT RETURN TO STORE
To order missing or replacement parts, contact us



WARNING


1. Do not use this product unless all screws and bolts are securely tightened.
2. Check that all screws and bolts are tight every three months or as needed.
3. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
4. Do not use this product as a stepladder.
5. Use this product for its intended purpose only.
6. **Intended for residential use only.**

LIMITED WARRANTY


We warrant to the original purchaser our products to be free from defects in material and workmanship for a period of 5 years. Defects and damage from misuse, abuse, negligence, alteration, accident, vandalism, rusting, acts of nature or any other event beyond the control of us is not covered. The warranty does not cover cosmetic damage that may result from normal use. Liability for incidental or consequential damages is excluded. The user assumes all risk of injury resulting from use of this product. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

To make a warranty claim, contact Customer Service, provide model number, sales receipt and description of the problem. It is the customer's responsibility to prepay freight on any components returned to the factory. We will pay return freight on components covered under terms of warranty.


PARTS LIST




(1) Top Panel (1 PC)




(2) Connection Panel (1 PC)



(3) Post (1 PC)



(4) Base Panel (1 PC)



(5) Foot Pad (3 PCS)


THANK YOU for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts and hardware lists.

HARDWARE LIST

NO	SKETCH	DESCRIPTION	SIZE	Q'TY
A		BOLT	ø5/16" X 35mm	13 PCS+ 1 EXTRA
B		FLAT WASHER	ø5/16" X 19 mm	13 PCS+ 1 EXTRA
C		SPRING WASHER	ø5/16"	13 PCS+ 1 EXTRA
D		WRENCH	5 mm	1 PC


STEP 1:

Attach Connection Panel (2) to Post (3) using three Flat Washers (B), three Spring Washers (C) and three Bolts (A).
TIGHTEN ALL BOLTS USING WRENCH (D).




STEP 2:

Attach Connection Panel (2) to Top Panel (1) using four Flat Washers (B), four Spring Washers (C) and four Bolts (A).
TIGHTEN ALL BOLTS USING WRENCH (D).




STEP 3:

Attach Base Panel (4) to Post (3) using three Flat Washers (B), three Spring Washers (C) and three Bolts (A).
TIGHTEN ALL BOLTS USING WRENCH (D).



STEP 4:


Attach Foot Pads (5) to Base Panel (4) using one Flat Washer (B), one Spring Washer (C) and one Bolt (A) for each Foot Pad (5). **TIGHTEN ALL BOLTS USING WRENCH (D).**




IMPORTANT: MAKE SURE BOLTS ARE SECURELY TIGHTENED BEFORE USING THIS PRODUCT.

STEP 5:

Adjust levelers to level table.





FURNITURE CARE:

- Dust with a soft cloth following the grain pattern of the wood.
- Dust often to remove the everyday abrasive particles from the wood surfaces.
- Before dusting, moisten cloth lightly with a spray product.
- Wood finishes also benefit from an occasional polishing.