CUSTOMER SERVICE & WARRANTY

We have been rooted in the personal care industry for many years. At Prasky, we value every customer's trust and are dedicated to delivering the best in both product performance and customer support.


Prasky offers a 1-year warranty + 30-day return/exchange policy + lifetime support for this product. We will provide the best service for our brand's customers.

For any user manual problem, missing accessories, damaged package, any questions or feedback, or if you want to extend the warranty for one more year,
Please contact our customer support team at

support@praskylife.com
praskylife.com
1-866-228-7981

In order to help you solve the problem efficiently, please send us the following information when you contact us.
*Amazon order number
*A brief description of the problem: problem + the efforts you tried + photos/video

Product Components





① Protect cover
② Shaving unit
③ Power button
④ LED display
⑤ Charging port
⑥ Cleaning brush
⑦ USB cable
⑧ Nose trimmer
⑨ Sideburn trimmer
⑩ Pouch bag

How to Use

Charging

1. Please make sure that the power is off before charging.
2. Two charging methods
① AC Charging - Connect the USB interfaces of the shaver and charge by data line. It is recommended to use 5V ⎓ 1A charging equipment to charge this product.
② USB Charging - Connect the USB charging line to the USB interface or the power bank to charge.
3. Keep the shaver connected until fully charged (approximately 2h). The battery charge percentage and the battery symbol keep being indicated while charging.
4. The display will show 90M when fully charged, and then disconnect the charger from the outlet.
5. After charging, store the charger and shaver in a safe place and avoid sun exposure.





Shaving

1. Press the power button to turn on the shaver.
2. Rapidly move the shaver back and forth against the growing direction of the beard or hair.
3. Neck hair can also be shaved.
4. Cover with the protect cover to avoid damage after using.





Attaching / Detaching Attachments

1. All attachments (shaving unit, nose trimmer, sideburn trimmer) can be attached and detached in the same way.
2. Pull the shaving unit straight off the appliance.
(Note: Do not twist the shaving unit while you pull it off the appliance.)
3. Insert the lug of attachment into the slot at the top of the shaver. Then press down the unit to attach it to the appliance.
4. You can hear a clear "click" sound when it is installed correctly.





Travel Lock

1. Activating the travel lock - Press the power button for 3 seconds to activate the travel lock, and 🔒 will light up on the LED display.

PRASKY


Learn more about Prasky, please visit us at

praskylife.com

Support Online Instant Chat

Made in China


2. Deactivate the travel lock - Press the power button for 3 seconds to deactivate the travel lock, and 🔒 will be extinguished on the LED display. It can also be turned off by charging.



Cleaning & Maintenance

To ensure a better shaving effect, the shaver must be cleaned regularly.
1. Please switch off the shaver and separate it from the charging cable before cleaning.
2. Hold the razor to pull the blade holder, and remove the shaver part.
3. The shaver part can be washed directly, keeping the charging port dry while washing the body of the shaver.
4. You can use the cleaning brush to clean the shaver heads and hair chamber.
5. After rinsing, drain the water from the razor and place it horizontally in a ventilated area to dry.
6. For the best using experience, please add some lubricating oil (not included) every three months.
❗ Tips: Please contact us if you need to replace the damaged/old razor.





Caution

To reduce the risk of fire, electric shock, or personal injury when using, please follow these basic safety precautions.
1. This appliance can be used by adults. Children shouldn't use this appliance without supervision.
2. Check the blades before use. Don't use the appliance if the blade damaged.
3. Use the supplied charger only when recharging the appliance.
4. Do not wash the shaver with water hotter than 60°C.

Technical Specifications

Model	SK2
Power	5W
Voltage	3.7V
Input	5V⎓1A
Charging Time	2 hours
Using Time	About 120 minutes
Battery Capacity	800mAh
Battery Type	Lithium

PRASKY

3 in 1 ELECTRIC SHAVER



SK2

User Manual

背

正

尺　寸：360*130四折页，折成品90*130
材　质：105克铜
颜　色：PANTONE 5477C
日　期：2023/12/18
版本号：V4.0