


ASSEMBLY INSTRUCTIONS




V-ET25-0839A

PF050




WARNING !

MAXIMUM LOAD
220 lb / 100 kg



Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.

Make sure no parts are missing or damaged before assembly.

PACKAGE CONTENT

Board Identification


Not actual size




X2

BOARD IDENTIFICATION


Not actual size




① x2




② x2




③ x2




④ x2




⑤ x2




⑥ x2




⑦ x2




⑧ x2




⑩ x2




⑪ x4




⑫ x4



⑬ x4














⑭ x4







⑮ x4

HARDWARE LIST




Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.




PF050



F	x 36
---	------


STEP 3

PF050




X2


Note: Install according to the orientation specified in the instruction manual.



STEP 4





X2



STEP 5

PF050





X2

			
Ø15x9.5		Ø6x30	
G	x 12	A	x 4

STEP 6

PF050




X2

			
Ø15x9.5		Ø6x30	
G	x 12	A	x 4


STEP 7

PF050





X2

STEP 8




X2




STEP 9



PF050






Note: Part (I) must be securely fastened to the side panel with screws






X2



STEP 10




X4




STEP 11


PF050




X4




STEP 12



X4






X4

	
Ø3.5x12	
B	x 24

	
DL	
H	x 4

	
DR	
H	x 4



X2

FURNITURE CARE AND MAINTENANCE

Medium - Density Fiberboard and Particle board

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



MAINTENANCE

- Tighten all bolts and screws again within the first 2 weeks of assembly
- Check the tightness of all bolts every 2 months, tighten them if necessary



CLEANING

- Clean the surface of the MDF (medium - density fiberboard) or PB (particle board) with a lightly dampened cloth.
- Small amount of mild soap can be used if necessary
- Dry the surface immediately after cleaning.

⚠ DO NOT use bleach or alcohol detergent to clean the surface.

⚠ DO NOT apply wood treatment on parts made with MDF and PB.

Medium - density fiberboard and Particle board will swell and distort when suffer from water damage.

Make sure to dry the furniture immediately after cleaning