


WALKER EDISON™

Walker Edison EZ Assembly™ 70" TV Stand

SKU# WEGIS21702



For Residential Use Only

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com



Time to get started

Set up a clean and soft workplace to get started and avoid damage during the assembly. It also helps to double-check that you've got all the pieces and parts before diving in to assembly.


Estimated time for assembly

Say Goodbye to Frustration!
30 Minutes or Less to Build
No Tools Required



People recommended for assembly


Make it a team effort! Grab a friend for quicker, easier assembly.



2 People Build


Tools Needed

Grab a Phillips head screwdriver to conquer this assembly



Use power tools with caution


You can cause cracking or damage to the material and easily strip the hardware. If you choose to use a power tool, your product will no longer be covered under Walker Edison's warranty.



Scan to get assembly tips and help!



WE Parts List

Part Number	Description	Quantity
1	Top Panel	1
2	Bottom Panel	1
3	Left panel	1
4	Right Panel	1
5	Left Dividing Panel	1
6	Right Dividing Panel	1
7	Fixed Shelf	1
8	Adjustable Shelf	2
9	Back Panel	1
10	Top Back Support Rail	1
11	Top Front Support Rail	1
12	Bottom Back Support Rail	1
13	Bottom Front Support Rail	1
14	Bottom Frame	1
15	Left Door	2
16	Right Door	2





Hardware List


Part	Size	Name	Quantity
A	 6x30mm	Wooden dowel	32
B	 Ø1/4"x30mm	Thumb Screw	34
C	 Ø5/32"x25mm	Thumb Screw	2
D	 8x5x16mm	Shelf support pin	8
E	 4x15mm	Screw	2
F	 4x25mm	Screw	2
G		Plastic strap	2
H		Wall Anchor	2
J		Glue tube	2

*The hardware quantities listed above are required for proper assembly.
Extra hardware pieces may be included.*

Introducing Walker Edison EZ Assembly™ Hardware

At Walker Edison, we understand that furniture assembly can be a daunting task, especially when you're excited to get your new furniture set up and in use.

That's why we're introducing our innovative **Walker Edison EZ Assembly™** hardware system. Our goal is to make the assembly process as smooth and straightforward as possible, so you can spend less time building and more time enjoying your new furniture.




What Makes Walker Edison EZ Assembly™ Special?

- **Simplified Process:** Our hardware is designed to streamline the assembly process. With the Walker Edison EZ Assembly™ system, pieces connect easily and securely with minimal effort. No more fumbling with complex tools or trying to decipher confusing instructions—just quick, straightforward connections.
- **No Tools Required:** The Walker Edison EZ Assembly™ system is designed to be intuitive and user-friendly requiring no tools for assembly, so you can assemble with confidence, knowing it will be stable and secure.
- **Durable and Reliable:** Our Walker Edison EZ Assembly™ hardware isn't just easy to use—it's built to last. The components are crafted from high-quality materials to ensure that your furniture remains sturdy and reliable for years to come.

We're excited to introduce you to a new era of furniture assembly. With Walker Edison EZ Assembly™, you can look forward to a hassle-free experience and a beautiful, durable product that's ready to enjoy in no time.



How to Get Started




1. Get your panels ready, following the Assembly Instructions.
2. Match up the triangular male and female pieces—think of it as a little puzzle!
3. Let gravity lend a hand as you slide the hardware together at each aligned hardware piece.
4. Give the thumbscrew a twist in the center to lock everything in place.

Step 1

Let's get started! Grab your dowels (A) and pop them into the Bottom Panel (2).




Tip




1: The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.

2: In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.




Tip

To keep your product looking its best and scratch-free, try assembling it on a soft surface like carpet or a blanket. This helps prevent any accidental scratches and keeps your furniture in top shape!




Step 2

Insert dowels (A) into the Bottom Back and Front Support Rails (12 & 13).




Step 3

Attach the Bottom Back Support Panel (12) to the Bottom Panel (2) using thumb screws (B).




Step 4

Now do the same with the Bottom Front Support Panel (13).




Step 5

Insert dowels (A) into the Left and Right Panels (3 & 4).




Step 6

Attach the Left Panel (3) to the Bottom Panel (2) by matching up the EZ Assembly hardware and sliding the pieces together. Lock everything together with thumb screws (B). Lock everything together with thumb screws (B).




Step 7

Repeat that process with the Right Panel (4).




Step 8

Attach the Bottom Frame (14) to the Right and Left Panels (3 & 4) using thumb screws (B).




Step 9

Grab more dowels (A) and insert them into the Left and Right Dividing Panels (5 & 6), plus the Fixed Shelf (7).




Step 10

Attach the Fixed Shelf (7) to the Left Dividing Panel (5) with thumb screws (B).




Step 11

Now attach the Right Dividing Panel (6) with thumb screws (B).




Step 12

Attach the Left and Right Dividing Panels (5 & 6) to the Bottom Panel (2) by lining up the pins and flipping the levers once in place.




Tip

Quick Assembly Pin




1. Make sure the quick assembly pin is aligned with the corresponding hole.



2. Once the pin is inserted correctly, flip the metal lever in the opposite direction to ensure the panels are firmly locked together.


Step 13

Slide the Back Panel (9) into the groove on the back. It should glide right in.




Step 14

Insert dowels (A) into the Top Back and Front Support Rails (10 & 11).




Step 15

Attach the Top Back Support Rail (10) to the Left and Right Panels (3 & 4) by matching up the EZ Assembly hardware and sliding the pieces together. Lock everything together with thumb screws (B).




Step 16

Repeat that with the Top Front Support Rail (11).




Step 17

Gently place the Top Panel (1) on top. Line up the dowels, and secure it with thumb screws (B).




Step 18

Add the shelf support pins (D) then set in the Adjustable Shelves (8).





Step 19

Attach the Left and Right Doors (15 & 16) by sliding the long piece into the hardware on the case and clicking it into place.




Step 20

Make any necessary adjustments to the cabinet doors.




Tip


Adjusting The Cabinet Doors



Adjust horizontal width
with this screw.




Adjust depth position
by loosening the hinge arm
mounting screw.



Adjust vertical height
via the screws in the
mounting plate.


Step 21

Lock in the Back Panel (9) with thumb screws (C) right in the center. Then grab your safety tip kit: attach the plastic strap (G) to the top with screws (E).



Step 22


Finally, anchor the other end of the plastic strap (G) to your wall with the wall anchor (H) and screws (F).



Warning

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

Final Assembly



Congratulations on your new piece of furniture!

We would love to hear about it and see it.
Please leave us a review or post a picture with
#mywalkerredisonhome

Assembling furniture can be tricky sometimes.

Our customer service team, located in Utah, is here for product information, help assembling a product, or for any other customer support issue

Call us at **801-433-3008**

Email us at service@walkeredison.com

Visit our Customer Service website at
walkeredison.com/pages/customer-service

We are available to help Monday -Thursday 8am-5pm, Friday
8am-3pm MST

For details on Assembly Videos, Assembly Instructions,
Replacement Parts, and Customer service,
SCAN HERE

