

10ft.x10ft. Slant-leg POP-UP INSTRUCTION MANUAL



IMPORTANT INFORMATION:

IMPORTANTI: READ THIS INSTRUCTION CAREFULLY BEFORE PROCEEDING.

Make sure all parts listed below have been included in your package.

	ILLUSTRATION	DESCRIPTION	QTY
1		CANOPY ROOF	1
2		FRAME	1
3		CARRY BAG	1
4		STAKE BAG	1
5	\longrightarrow	STAKE	8

THIS PRODUCT REQUIRES TWO ADULTS TO ASSEMBLE.

In order not to damage the frame:

- Do not drop carry bag.

- Do not bounce bag on its end to remove product.

Note:

- Verify package contents by emptying contents of bag(s) and confirming all parts are included and undamaged.

- Verify all contents at home before you leave on your trip.

HOW TO SET UP

1.Pull and extend the frame

A) Select a smooth, level site for your pop-up.

B) With two people on diagonal corners of the structure, each grab a leg and have one person stand in place while the other walks the frame out.

C) Slide the roof lock mechanisms located on each leg, up toward roof corners, two legs at a time; At each leg, listen for lock to "click" into place. Stop adjusting frame legs at mid-level (half-way mark) for the next step.

2. Cover the Frame with Fabric Shell

A) Lay the fabric over the roof.

B) Line up all corners, adjusting from opposite sides. Fabric will fit snugly.

C) Locate the nylon fasteners on the underside of fabric body. Attach to roof frame. Watch out for your fingers.

3.Extend the Slanted Legs

A) Step on frame leg base, working from opposite sides.

B) Slide the lock mechanisms (located on upper leg portion) upwards until they lock into place. The amount of force necessary will be much less if you ensure the leg segment remains in its slanted position.

(Do not try and straighten the legs as this could damage the frame).

4.Stake Pop-up

A) Stake pop-up by driving stakes through the holes at the foot of each leg. **Tip:** Use additional weights (sand bags, other heavy objects) on each foot or place legs twelve inches down into sand to help secure set up for beach use. Stakes alone will not secure pop-up in sand or soft soil.

B) To secure guy lines, find the guy line plastic slider and look for portion of the line opposite the knot. Pull this portion, forming a loop (works like a slip knot). Extend guy line to ground and stake. Repeat with remaining guy lines.

HOW TO TAKE DOWN 1.Remove the Stakes

Carefully remove stakes by pulling out the hook ends. Remove excess soil from the stakes.

2. Taking Down the pop-up

A) Press the snap button located in the middle of each leg and carefully lower two legs at a time. Continue in this manner until frame legs are again at mid-level (half-way mark).

B) Detach all fasteners and remove fabric shell completely off frame and fold for storing. Remember the fasteners are on side scissors bars and at corners.

NEVER STORE FABRIC ON FRAME. YOU MAY DAMAGE FABRIC, FRAME OR BOTH.

C) Press the snap butons found on each leg at each upper corner of frame, making sure that all sides are detached from snap button.


D) Slowly slide roof line downward while walking in. This should collapse frame completely.


3.Store in Carry Bag

A) To prolong the use of your pop-up you will want to store it correctly. After folding, place frame inside the carry bag.


B) Return stakes to their bag.

C) Fold the canopy roof and carefully place it into carry bag with frame and carefully zip carry bag closed.




















IMPORTANT INFORMATION

IMPORTANT! Read this information before proceeding.

It is the user's responsibility to take the following precautions at all times:

- Always stake or weigh down your pop-up. Do not use in any potentially windy or rainy weather.
- Wind and rain can damage the pop-up and may also result in injury to you or others. Therefore, do not rely on pop-up for protection in heavy or prolonged rain storms.
- The pop-up is designed as a temporary pop-up. Do not leave up for extended periods.
- Use caution when handling the pop-up folding frame. Avoid pinching hands or fingers as frame opens or closes.
- Do not use pop-up in a lightning storm.
- Do not leave your pop-up unattended.
- Do not build fires within pop-up enclosure.

WARNING:

Keep all flame and heat sources away from all pop-up fabrics. These fabrics meet the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the fabric may render the flame-resistant properties ineffective.

THIS FABRIC IS NOT WATERPROOF!

Your product's fabric is a synthetic material that has been treated and is not only highly-resistant to the sun's Ultraviolet (UV) light but also highly water-repellent in light rain conditions.

CARE & MAINTENANCE

For long lasting durability and the best possible protection for your pop-up, follow these care and maintenance.

Instructions:

- Your product is NOT machine washable. Your product is NOT machine dryable. Use a mild soap (not detergent) and plenty of water for top cleaning.
- Let the canopy roof and frame dry completely before closing or storing to avoid mildew.

- Frame will operate and look better if occasionally wiped with silicone spray, especially before and after use in damp conditions. Remove excess silicone residue before applying top.

- Use a seam sealer if top leaks or drips water. Available at most sporting goods and hardware stores.
- Slightly tighten bolts if frame becomes loose.

CONTACT US FOR HELP

Customer Service: service@abbapatio.com Need Assistance? Call 833-597-5944

Hours of Operation:

Phone Support: Monday - Friday: 6:30 am - 4:30 pm PST Email Support: We are available 24 hours a day, M-F. Please allow up to 24 hours for a response.

Note: Our team is available to assist you during these hours. If you have any inquiries or require support outside of these hours, please leave a voicemail, send an email. We will get back to you promptly during the next available support hours. We thank you for your purchase!