





ASSEMBLY INSTRUCTION



Dining Chair




Component List

LABEL		DESCRIPTION	QTY
A		Back	1
B		Seat	1
C		Leg	1
D		Leg	1

Hardware List


LABEL		DESCRIPTION	QTY
H1		Bolts M6×35mm	4
H2		Bolts M6×16mm	4
H3		Bolts M6×30mm	1
H4		Washer M6×18×1mm	4
H5		Allen key M6	1
H6		Allen key M4	1

1




Tighten the screws to 70% tightness.

2




Tighten the screws to 70% tightness.

3



Tighten the screws to 70% tightness.

4



It is an adjustable foot nail that can adjust the height when the four feet are not flat.

Adjust the chair so that it is leveled, then fully tighten all the screws.