



# KISSES ROCKING DOLL BASSINET

**Assembly and Use Instructions. Adult Assembly Required.**  
**Read all instructions before use. This manual is part of the product**  
**and must be saved for future reference.**



**MODEL NUMBER\*:**  
**17920**

**VERSION CODE\*:**  
**1.0/0417/TG**

*\* Model and Version numbers are needed if  
replacement parts are requested*

**FOR REPLACEMENT PARTS:**  
**<http://www.badgerbasket.com/parts>**

Badger Basket, PO Box 227, Edgar, WI 54426-0227 USA • **Web:** [www.badgerbasket.com](http://www.badgerbasket.com)  
**U.S. Based Customer Service Toll-Free** (Mon-Thurs 7:00 AM-4:00 PM CST): 1-800-236-1310  
**Phone:** 715-352-2311 • **Fax:** 715-352-3163

1.0/0417/TG



## **BEFORE YOU BEGIN ASSEMBLY:**

Check all parts and hardware. If anything is missing or not satisfactory, please DO NOT call the store or return the product to them. Please go online to:

**<http://www.badgerbasket.com/parts>**

Most problems are resolved without you needing to leave home.

If emailing or calling us, please have this instruction manual, your product model number, and your Version Code ready.

**Your Model Number is: 17920**

**Your Version Code is: 1.0/0417/TG**

## **CARE INSTRUCTIONS:**

Use cold water and mild detergent for any and all cleaning.

FRAME: wipe clean with a damp cloth dry thoroughly. LINER/SKIRT AND CANOPY: spot clean or remove from frame and machine wash, tumble dry low or no heat. Secure all grip tape before washing. PADDED BOTTOM BOARD: gently spot clean.




## **WARNING - CAUTION**




**ADULT ASSEMBLY REQUIRED**  
DUE TO THE PRESENCE OF SMALL PARTS AND SHARP POINTS DURING ASSEMBLY, KEEP OUT OF REACH OF CHILDREN UNTIL ASSEMBLY IS COMPLETE.


**READ ALL INSTRUCTIONS** before use of this product. Use only the parts and hardware provided by Badger Basket. Keep instructions for future use. Do not use the product if it is damaged or broken. Periodically inspect the product and retighten hardware if needed. **This item is a toy for dolls only.** It is never to be used for real children or pets. **For children ages three (3) years and older. Never attempt to sit or stand on the toy.**  
**No product is a substitute for adult supervision.**  
**Always supervise your child during play.**



**BODY**  
A×1




**CANOPY FRAME**  
B×1




**ROCKER LEG**  
C×2




**CANOPY POST**  
D×1




**CANOPY**  
E×1



**BASKET**  
F×1




**LINER/SKIRT**  
G×1




**BOTTOM BOARD**  
H×1


1




2




3



4



5



6

