


















Please unscrew all hardware from cushion before assembly.
Por favor de destornillar todos los tornillos del cojín antes de ensamblar la silla.

(1)x1	(2)x1	(3)x1 (L)x1 (R)									
											
Back	Seat	Right & Left Arm									
(4)x 1	(5)x1	(6)x1									
											
Mechanism	Gas Lift	Base									
(7)x 5	<table border="0"> <tr> <td>(A)*8</td> <td></td> <td>M6*18 ARM SCREW</td> </tr> <tr> <td>(B)*8</td> <td></td> <td>ARM CAP</td> </tr> <tr> <td>(C)*4</td> <td></td> <td>M8*22 MECHANISM SCREW</td> </tr> </table>		(A)*8		M6*18 ARM SCREW	(B)*8		ARM CAP	(C)*4		M8*22 MECHANISM SCREW
(A)*8		M6*18 ARM SCREW									
(B)*8		ARM CAP									
(C)*4		M8*22 MECHANISM SCREW									
											
Casters											



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.

