









Dining Chair Assembly Instruction



Ax1		Bx1		Cx2		Dx4	
SEAT		BACK FRAME		LEGS		SCREW(8*70MM)	
Ex5		Fx9		Gx9		Hx1	
SCREW(8*65MM)		PLASTIC GASKET		WASHER		ALLEN KEY	

STEP 1

