



















Assembly manual




Accessories List

Ax1 	Bx1 	Cx1 
Dx1 	Ex1 	Fx1 
Gx5 	Hx7 	Ix1 
Jx2 	Kx2 	Lx1 
Mx11  M6x14mm	Nx11  M6x25mm	Ox10  M6x20mm
Px1 		


Step 1




Step 2




Step 3




Step 4




Step 5




Step 6




Step 7




Step 8




Step 9




Step 10




Step 11




Step 12




Step 13



Step 14





ONLY ON THE SEAT, NOT THE FOOTREST