


# NEON LED SIGN WITH ANIMATION-BAR

## USE INSTRUCTIONS:

### How to use?

1. Determine a location for the LED sign. This item is for INDOOR USE ONLY.
2. You can either hang this using a metal chain (included) or wall mount using two triangle hooks located on the back of the sign.
3. Plug into 110V AC electrical outlet.
4. Turn on the LED sign by using the ON/OFF power switch located on the cord (Figure 1)
5. Turn on the LED lights by using the red button on the side of the sign (Figure 2). You can press the button for either a static or animated mode.



**NOTE:** Use the hanging chain (included) and an extension cord (not included) if you are placing the item in a higher location and need a longer power connection.

## Product specifications

Theme/Design:	BAR	Length (Inches):	19"
Finish:	Black	Width (Inches):	0.9"
Light Type:	LED	Height (Inches):	10"
Light Quantity:	127 X LEDs	Power Cord Length (ft):	4.5'
Light Color:	red, blue, yellow	Indoor/Outdoor:	Indoor only
Light Bulb:	Non-replaceable	Power Source:	Plug-in
Light Lifespan	100,000 hrs	Material:	Plastic

### Packaging List:

- 1.) 1 X LED Sign (Dimension: 19"X0.9"X10") with 4.5 feet power cord
- 2.) 1 X Metal Chain (Length:19.65")
- 3.) 1 X Use Instruction Sheet