


Assembly Instruction Sheet for Model 473059

Package Contents

Part	Description	Quantity
A	Fixture Body	1 pc.

A



STEP 1

Remove the lamp shade from the Fixture Body(A).

STEP 2

Mark the drilling position on ceiling with the help of the backplate of Fixture Body(A). Drill holes on the marks and stick the expansion anchors into the holes.

STEP 3

Thread the wire through the hole of the backplate of Fixture Body(A). Fix the backplate to the expansion anchors with self-tapping screws.

STEP 4

Connect live line to wire color Black/Red from the backplate of Fixture Body(A).
Connect neutral line to wire color White/Blue from the backplate of Fixture Body(A).

STEP 5

Attach the lamp shade to the backplate of Fixture Body(A).

Your fixture is now assembled and ready to use.