

Assembly Instruction Sheet

SKU# 5081-LR-400 - WINSTON CONSOLE TABLE

Thank you for your purchase.



Before discarding packaging material be sure to locate all parts including the necessary hardware and tools listed in the instruction sheet below.

Please read all instructions before unpacking assembly parts.

Also, exposed staples can cause injury, for your protection carefully remove any staples used in the packaging.


Parts/Hardware list:

NO#	DESCRIPTION		QUANTITY
A	BOLT	1/4"x 3/4"	24 PCS
B	BOLT	1/4"x1 9/16"	14 PCS
C	SPRING WASHER	1/4"	38 PCS
D	FLAT WASHER	1/4"x13x1mm	38 PCS
E	WOOD DOWEL	Ø8X30mm	4 PC
F	METAL BRACKET	32*18*21*2mm	12 PC
G	ALLEN KEY	M4x59mm	1 PC

NO#	DESCRIPTION		QUANTITY
1	TOP PANEL		1 PC
2	SHEFL PANEL		1 PC
3	BOX		1 PC
4	BOTTOM PANEL		1 PC
5	LEGS FRAME		6 PCS

Step 1



Diagram assembly





Customer Help Line
1-276-629-3341 EXT 3206

Step 2


Note: The bolts do not too tightened.



Step 3



Step 4



**Note: Finish, Tighten all bolts
after adjusted between the legs and the table top.**

