


ASSEMBLY INSTRUCTIONS




TOOLS REQUIRED:

Allen Wrench (supplied, part # A)


BEFORE YOU START:

1. Check the parts against the parts list to make sure all items are present.
2. Assemble your furniture on a soft, flat surface to avoid scratching the finish.
3. CAUTION: Do not over tighten screws, nuts or bolts during assembly.
4. Your furniture may require occasional tightening.




INSTRUCTIONS:

1. Set the top upside down onto a smooth and clean soft surface.
2. Attach the Legs to the table top using **Bolt (B)**, **Lock washer (C)**, **Flat washer (D)** and **Allen Wrench (A)**, See Figure 1.
3. Attach the stretcher to the bottom of the legs, using **Bolt (B)**, **Lock washer (C)**, **flat washer (D)**, and **Allen Wrench (A)**, See Figure 2.
4. Attach the **Corner block** to the Legs and Top with **Bolt (B)**, **Lock washer (C)** and **Flat washer (D)**, See Figure 3.
5. Tighten all bolts before using the table.
6. Turn the assembled unit upright, as figure 4.



Notes: There are levelers on the supports under the table top, if the top is not flat after leaves are open, you can slide out the supports and adjust by turning the leveler as figure 4.



No.	Hardware List		Q'ty
A		Allen Wrench	1pc
B		BOLT (Ø 8mm*45mm)	10pcs
C		LOCK WASHER (Ø 8mm)	10pcs
D		FLAT WASHER (Ø 8mm)	10pcs

Thank you for purchasing furniture