


KITCHEN ISLAND CART

Assembly Instructions - Please keep for future reference

N707P531456 / N707P531457



Important - Please read these instructions fully before starting assembly.




Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to lay out the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING

In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-











Use the anti-tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases, more fittings may be supplied than required.

HARDWARE BOX INSIDE BOX 2





A QTY: 41+2 	B QTY: 41+2 	C QTY: 28+2  Ø6*30mm	D QTY: 12  Ø4*25mm
CAM BOLT	CAM LOCK	WOOD DOWEL	FLAT HEAD SCREW
E QTY: 4 	F QTY: 30+2  Ø3*12mm	G QTY: 7 	H QTY: 90+2  Ø3.5*15mm
BALL BEARING SLIDE	FLAT HEAD SCREW	BUTT HINGE	FLAT HEAD SCREW
I QTY: 16 	J QTY: 8 	K QTY: 6 	L QTY: 12  Ø4*15mm
SHELF PIN	HYDRAULIC HINGE	HANDLE	HANDLE BOLT
M QTY: 16  Ø6*12mm	N QTY: 13  Ø6*32mm	P QTY: 6 	Q QTY: 6 
BOLT	BOLT	SPRING WASHER	FLAT WASHER

Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases, more fittings may be supplied than required.


HARDWARE BOX INSIDE BOX 2

<div>R</div> <div></div> <div>QTY: 8</div> <div>Ø4*30mm</div> <div>FLAT HEAD SCREW</div>	<div>S</div> <div></div> <div>QTY: 3</div> <div>DOOR STOPPER</div>	<div>T</div> <div></div> <div>QTY: 4</div> <div>LOCKING CASTER</div>	<div>U</div> <div></div> <div>QTY: 8</div> <div>Ø3.5*15mm</div> <div>PAN HEAD SCREW</div>
<div>V</div> <div></div> <div>QTY: 1</div> <div>HEX KEY</div>	<div>X</div> <div></div> <div>QTY: 2</div> <div>SPRING BALL LATCH</div>		

Using Camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4


Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.















COMPONENTS - KEY DIAGRAM



COMPONENTS - KEY DIAGRAM


BOX 1 : N707P531456

3  QTY: 1	4  QTY: 1	7  QTY: 1
LEFT SIDE FRAME	RIGHT SIDE FRAME	LEFT FRONT RAIL
8  QTY: 1	11  QTY: 2	12  QTY: 1
RIGHT FRONT RAIL	ADJUSTABLE SHELF	LEFT SUPPORT BRACKET
13  QTY: 1	14  QTY: 2	15  QTY: 1
RIGHT SUPPORT BRACKET	TOWEL BAR END BRACKET	TOWEL BAR
16  QTY: 1	17  QTY: 1	18  QTY: 1
BRACKET - RIGHT	BRACKET - LEFT	BRACKET BOTTOM
19  QTY: 3	25  QTY: 2	26  QTY: 3
PULL BAR	CONNECTOR BLOCK	CONNECTOR BLOCK

COMPONENTS - KEY DIAGRAM

BOX 1 : N707P531456

27




QTY: 1

28



QTY: 1

32




QTY: 2

LEFT DOOR

RIGHT DOOR


LEFT DRAWER SIDE

33



QTY: 2

34



QTY: 2


RIGHT DRAWER SIDE

DRAWER BACK

COMPONENTS - KEY DIAGRAM

BOX 2 : N707P531457


1



QTY: 1

MAIN TOP PANEL


2



QTY: 1

DROP - LEAF PANEL


5



QTY: 1

LEFT PARTITION PANEL


6



QTY: 1

RIGHT PARTITION PANEL


9



QTY: 1

BACK PANEL


10



QTY: 2

ADJUSTABLE SHELF


20



QTY: 1

BOTTOM PANEL


21



QTY: 1

FRONT BOTTOM RAIL


22



QTY: 1

BACK BOTTOM RAIL


23



QTY: 1

LEFT BOTTOM RAIL


24



QTY: 1

RIGHT BOTTOM RAIL


29



QTY: 1

LEFT CENTER DOOR


30



QTY: 1

RIGHT CENTER DOOR


31



QTY: 2

DRAWER FRONT

35





QTY: 2

BOTTOM DRAWER

Pay Slides Must Be Separated Berore Assembly.
After Separated, Set Aside Until Needed for Assembly.


STEP 1 : Extend Side

Pay attention when connecting !
The sliding module must be at the front end.



STEP 2 : Push Lever UP

Push the lever up to remove the runner.




STEP 3 : Remove Runner

ASSEMBLY INSTRUCTIONS


STEP 1

③ x1

④ x1




E1		2PCS
F		6PCS




STEP 2

⑤ x1

⑥ x1




E1		2PCS
F		6PCS




ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




ASSEMBLY INSTRUCTIONS

STEP 5

⑦ x1



⑧ x1

S		2PCS
F		4PCS



STEP 6

B		2PCS
---	---	------




ASSEMBLY INSTRUCTIONS

STEP 7

B



2PCS



STEP 8

D



12PCS


(21) x1

(23) x1

(24) x1

(25) x2


(26) x3




ASSEMBLY INSTRUCTIONS

STEP 9

A



8PCS




STEP 10

②② x1

B



4PCS




ASSEMBLY INSTRUCTIONS

STEP 11

B




4PCS



STEP 12

(20) x1

A




3PCS

C





2PCS



ASSEMBLY INSTRUCTIONS


STEP 13

B		3PCS
N		7PCS



STEP 14


T		4PCS
M		16PCS




Note: Engage the locks on all casters to prevent the cart from rolling during use.

ASSEMBLY INSTRUCTIONS

STEP 15




STEP 16



ASSEMBLY INSTRUCTIONS

STEP 17


⑨ x1




STEP 18

⑭ x2

⑮ x1



x2



N		4PCS
P		4PCS
Q		4PCS

ASSEMBLY INSTRUCTIONS


STEP 19






①⑥ x1

①⑦ x1

①⑧ x1


①⑨ x3

A		2PCS
B		2PCS
C		2PCS



ASSEMBLY INSTRUCTIONS


STEP 20




C		4PCS
N		2PCS
P		2PCS
Q		2PCS

STEP 21

① x1





A		8PCS
S		1PC
F		2PCS

ASSEMBLY INSTRUCTIONS


STEP 22

B		8PCS
C		8PCS



STEP 23

U		8PCS
---	---	------




ASSEMBLY INSTRUCTIONS

STEP 24

⑩ x2

⑪ x2



I		16PCS
---	--	-------


STEP 25

②⑦ x1

②⑧ x1

②⑨ x1

③① x1



J		8PCS
H		16PCS



ASSEMBLY INSTRUCTIONS

STEP 26

H



32PCS



STEP 27

K






4PCS

L



8PCS



x4



ASSEMBLY INSTRUCTIONS

STEP 28

③② x2

③③ x2

E2		4PCS
F		12PCS





STEP 29

③④ x2

③⑤ x2


R		8PCS
---	---	------



ASSEMBLY INSTRUCTIONS


STEP 30

A



8PCS

(31) x2



STEP 31

B



8PCS

K






2PCS

L




4PCS




ASSEMBLY INSTRUCTIONS

STEP 32



STEP 33


- ② x1
- ⑫ x1
- ⑬ x1



ASSEMBLY INSTRUCTIONS


STEP 34

H		12PCS
X		2PCS




STEP 35

H		9PCS
---	---	------




ASSEMBLY INSTRUCTIONS

Finish!





ASSEMBLY INSTRUCTIONS



When the hinges are installed, you can refer to the pictures to adjust the screws of the doors till it's perfect.





1. Adjust the screws shown in Figure 1 to adjust the door up and down.



2. Adjust the screws shown in Figure 2 to adjust the door left and right to the right position.



3. Adjust the screws shown in Figure 3 and pull the door back and forth so that it can be opened smoothly.



4. After the adjustment is complete, secure the remaining two screws to secure the door in place.