

# Instruction Manual

---

## Broken Egg Shell Waterfall Fountain



# Warranty

## Limited 1-Year Manufacturer Warranty

**Manufacturer warranty covers:**

- Parts that are deemed defective within 30 day will be shipped free of charge.
- Any warranty claim after 30 days, will require shipping to be paid by the customer.

Any visible damage due to the neglect, misuse, or abuse will void the limited warranty of the product.

# Contents

<b>Contents .....</b>	<b>2</b>
<b>What is included .....</b>	<b>3</b>
<b>Assembly instructions .....</b>	<b>4</b>
<b>Warranty .....</b>	<b>5</b>

## What is included



A. Fountain




B. Hose and LED lights




C. Auto Shut Off Pump


## Assembly instructions




1  
Connect LED and Hose to the fountain



2  
Connect Hose to the Pump



3  
Connect LED to the Pump



4  
Completely submerge pump in water

