


Ahokua

Assembly Instruction

Accent cabinet



Assembly Instruction

Thanks for buying this Living Room Furniture.

⚠ WARNING:

- Read all instructions carefully and completely before assembly and use.
- Retain for future reference.
- DO NOT use power tools.
- DO NOT over-tighten hardware.
- Periodically check all hardware and re-tighten as necessary.
- DO NOT use product if any component becomes damaged.
- For residential (non-commercial) use only.
- DO NOT sit or stand on product. Use only for intended purpose.
- DO NOT exceed 50lbs for the tabletop, 10lbs for drawer, evenly distributed.

Parts List

Check all parts before assembly

A. Table body




*1

B. Leg (Short)



*2

C. Leg (Long)




*2

H1. Foot pad




*4

Step 1: Put the Table body (A) on a soft surface to protect the finish. Insert the threaded end of the Legs (B&C) into the Tabletop(A) and turn it clockwise to tighten. Attach the Foot pad (H1) to the bottom of the legs.



Assembly finished.



Notice:

If you encounter any issues during installation or use, please email us at support@mi-din.com, including your order ID and a detailed description of the problem. If possible, please provide relevant images to expedite assistance. We will strive to resolve any issues promptly.