



Assembly Instruction




Coffee table & Dining table










ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Parts List

Number	Name	Part	Qty
1	Desktop		x1PC
2	Leg		x5PC
3	Footrest		x1PC

Number	Hardware	Part	Qty
A	M6*30mm		x15+1EXT
B	Allen Wrench		x1PC
C	Foot		x5+1EXT



Additional Note About Safety: Bolts may loosen during normal everyday use. They should be periodically inspected and tightened to prevent damage or injury. Always check to be sure that all hardware is kept tightened. Thank you for your purchase.