

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

SOFA TABLE

723449

ITEM : 723449

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2.This product is for home use only and not intended for commercial establishment.





ASSEMBLY TIME


10 MINUTES


PARTS IDENTIFICATION


Z-HARDWARE

A TOP  **1PC**

B BASE  **1PC**

1 BOLT 8X35MM  **4PC**


2 WASHER φ20X2MM  **4PC**

3 ALLEN KEY 30X80MM  **1PC**


ITEM : 723449

ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2




STEP 3





Note: Dimension tolerance $\pm 5\%$



COASTERFURNITURE.COM