


Pet Grooming Vacuum Kit

Instruction Manual

CW-TMQ5N1-2L



✉ HJ-Customer-Service@outlook.com

☎ (909)637-7665 | (909)637-7593

EST 9:00AM--17:00PM

Safety Information

General Warning

- This product only for household use, not for commercial or industrial use, nor for outdoor or humid places;
- Never leave children or people with weak considering ability alone to use this product.
- Please ensure an environment where it can be used product safely and use it under the instructions and supervision of a person whom understand the safety use of the product and its hazards. Under such circumstances, keep away from children and pets, never leave the product on the place where children and pets can touch and play with.
- Please pay full attention, do not touch the plug and product with wet hands. Do not use this product absorb moisture and liquid.
- Please do not use the product while the power cord or power plug is damaged.
- Please do not use the product if the product not work normally or was damaged or immersed in liquid. Please be sure to contact our company. Please do not use the product if the product not work normally or was damaged or immersed in liquid. Please contact our company for repair services;
- Please do not inhale gas or any flammable liquid, and do not use it under the condition flammable or combustible near by.
- Please do not pull the power cord, do not put heavy objects on the top of the machine. Avoid the wire being clamped by the door when closing it.
- Please do not use the machine with smock. Do not use the machin absorb ash of match or cigarette when they are on fire, smocking or in high temperature. Make sure there nothing block the opening side before use the machine.
- Please pull off the plug from the socket after use, maintain the machine and parts replacement.
- Please do not use or keep it in humid places such as outdoor, bathroom or any other wet environment.
- Please do not use aromatic compounds or anything with fragrance as filter, such chemicals may cause the fire.
- Please use the machine under correct voltage, you can found correct voltage on the bottom of the machine.

Cautions


- **Please do not operate or unplug the power cord with wet hands.**
- In order to avoid malfunction and electric shock, please absolutely prohibit.
- **Please do not use it in the place where flammable. Avoid on fire or causing bomb.**
- Please do not use it near flammable liquid or anything flammable.
- **There may be a peculiar smell when used for the first time, but it will not cause effects on the body.**
- There will be an odor when use the product for the first time, but it will disappear after a while. Please kindly understand. However, if there have burnt smell persists, please stop using it immediately.
- **Please keep the dust cup and filter clean after use.**
- It may cause malfunction if the dust cup and filter getting dirty, and unexpected accidents may occur.
- **Please make sure the power off and unplug the power cord before proceeding with maintaining.**
- It will be danger of electric shock if turn on the power while maintaining, or cause the accidents and injuries.
- **Please stop using the machine when the temperature rises abnormally.**
- If abnormal heating of the motor occurs or the suction part is blocked, the operation will be stopped immediately, please take out the dust cup, confirm the suction part and filter are clean, and turn on it after 60 minutes.
- If the vacumm device indicator blinks and stop working, please clean the clipper knives/scissors and turn them back on.

Specifications

Wattage:	120W(1st gear),200W(2st gear),300W(3st gear)
Voltage:	120V
Hose length;	1.4M/4.6ft
Suction Level:	1st gear≥4Kpa, 2nd gear≥7Kpa, 3rd gear≥10Kpa
Dust Cup Capacity:	2.5L
Product Size:	337*152*208mm / 13.3*6*8.2inch
Wire Length:	2.5M / 98.4 inch
N.W.:	2.7KG / 6lbs
Noise Level:	1st gear≤65dB, 2nd gear≤70dB, 3rd gear≤73dB


1 Package List

A X1




Vacuum Device

B X1



Hose

C X1




Cleaning Brush

D X1



Nozzle

E X1




Electric Clippers

F X1




Roller Brushes

G X1



Grooming Brush


H X1



3MM

Clipping Comb


I X1



6MM

Clipping Comb


J X1



9MM

Clipping Comb


K X1



12MM

Clipping Comb


L X1



16MM

Clipping Comb

M X1



24MM

Clipping Comb

N X3




Lube Oil


Instruction For Use

Step 1

Button Description




Step 2



Follow the direction of the arrow symbol, insert one side of the Hose B to connect to the Vacuum Device A, and the another side to match the accessories.


Step 3

Introduction use of Accessories




Grooming Brush

It can clean the floating hair on pets and the garbage in the hair. At the same time it has the function of lengthen the hair, making the hair more fluffy.



Roller Brushes


Remove the loose hair of dogs and cats which have long or short hair more quicker and easier at home.



Electric clippers


It can shave your pet's hair and suck it into dust cup to prevent it from falling to the floor or somewhere else.

Note: Please be careful on the soft parts of the pet's skin and do not use excessive force to cause skin scratches.



Cleaning Brush

It can clean the hair of pets or remove the hair from clothes.





Nozzle

It can clean the sofa and somewhere needs vacuuming the dropped hairs.

Clipping comb

According to different hair style needs optional choose to use.


Note: The objects are scattered and small, please keep them properly when not in use.



Wind Cover

It used to enhance the suction force of the tuyere while trimming hair, and at the same time guide the oath of the suction part(optional use)

Note: The objects are scattered and small, please keep them properly when not in use.



Daily Maintenance

Step 4-1

Clean the Dust Cup



- 1: Remove the dust cup on the opening side in the direction of the arrow.
- 2: Open the lid and push the buckle to open the dust cup to dump out the trash.
- 3: Install the dust cup in the direction of the arrow.

Note: Please be careful when hanging the dust cup. Ensure the dust cup is dry after cleaned and dumped with trash to avoid that water ingress into the motor to cause electric shock or damage the machine.

Step 4-2

Clean the Electric Clippers


1. Please retract the removable knife to the bottom with adjustment knob before installing the knife.

2. Vacuum/clean debris from the blade and the clipper.


3. Drop the lubricant on the blade.




Remove the blade



Blade




clipper




Step 4-3


Clean HEPA




1. Please ensure power off, then remove the dust cup and take out the HEPA.



2. Washing it in cold water and drain the water.




3. Put it in a well-ventilated place for at least 24 hours of drying.




4. Please Install the HEPA back to the original place after it is completely dry.

Step 4-4


Clean the Sponge Filter



1. Please ensure power off, then remove the dust cup and take out the sponge.



2. Washing it in cold water and drain the water.




3. Put it in a well-ventilated place for at least 24 hours of drying.




4. Please Install the Sponge filter back to the original place after it is completely dry.

Step 4-5

Hose Storage Method



Wrap the hose clockwise around the fuselage, and the hose snaps into the buckle on the side of fuselage to fix it.



Technical Support

(909)637-7665 | (909)637-7593

Other Info

HJ-Customer-Service@outlook.com

Thank you for choosing this product. We strive to provide you with the best quality products and services in the industry. Should you have any issues, please don't hesitate to contact us.