









ASSEMBLY INSTRUCTIONS



PARTS LIST

LABEL	PICTURE	DESCRIPTION	QTY
A		Loveseat	1
B		Leg	5
C		Straight center leg	1

HARDWARE

LABEL	PICTURE	DESCRIPTION	QTY
D		Metal Gasket	18
E		Spring Washer	18
F		Screw	18
G		Wrench	1

BEFORE BEGINNING ASSEMBLY:



Read instructions cover to cover



Have two adults on hand for assembly



Do NOT assemble on flooring or carpet. Assemble on a clean non-marring surface (ex: packing foam)



Save all packaging until assembly is completed

STEP 1



The diagram illustrates a rectangular frame assembly. The main frame is labeled **A**. It consists of four corner joints, each labeled **B**, and four side supports, each labeled **C**. A circular inset provides a detailed view of the corner joint assembly, showing a bolt labeled **F**, a washer labeled **E**, and a nut labeled **D**. A label **G** points to the corner joint assembly in the main frame.

CARE & MAINTENANCE



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Dust and pick up spills using a clean, non-colored, lint-free cloth.



Stains may be removed with mild soap solution and a damp cloth.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside, for indoor use only.