


LED Bonsai Light Instruction

Direction for use:

1. Carefully remove product from package;



2. Unfold the tree base, connect the second half branch to the base and fix with screw; Connect the cable with transformer and plug into the power outlet.



The tree can be shaped by bending and arranging the branches into desired position to give it a natural appearance!

- Power supply: 24V adaptor, IP44 rainproof
- Input: 120V AC 50/60Hz
- Output: 24V DC 6W

IMPORTANT SAFETY INSTRUCTIONS

When in use outdoors, install only to a covered GFCI electrical outlet that is weather proof. Make sure the outdoor adaptor and cord are assembled correctly and secured tightly to prevent water from entering the device

1. Please read and follow all instructions and warnings both on the instructions and on the product carefully before use.
2. Retain these instructions for future reference.
3. This product is to be used only as intended its use.
4. Safe for indoor or sheltered outdoor use, Not designed to withstand heavy winds or storm conditions
5. If used outdoors, connect the product to a Ground Fault Circuit Interrupting (GFCI) receptacle.
6. Do not mount or place near gas or electric heaters, fireplaces, candles or other similar sources of heat
7. Do not secure the wiring of this product with staples or nails, or place on sharp hooks, nails or in a manner that can cut or damage the wire or insulation.
8. This is an electric product and not a toy! To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.
9. Do not close doors or windows on the product or extension cords as this may damage the wire and insulation.

Troubleshooting

1. If the whole tree doesn't light up.
Firstly please check if the components have been connected normally. Then please check whether the adaptor works well, including the plug cord has been connected properly to the adaptor in right position of male and female connection.
2. If one or more of the branches don't light up.
Please check each bulb on the unlighted branch has been well welded by touching slightly, or bending the branch slightly, if it doesn't work please follow step 3.
3. Any problem not mentioned above or unsolved
Please contact us for assistance.

Warranty

FAQ:

Q: How many times can each branch be bent ?

A: Please do not bend each branch more than 5 times as high-frequency bending will loosen the connection between branches and also affect the appearance. If there is a loose, you are advised to bind it with an electrical tape in similar color of branches.

Q: If one of the lights doesn't work, will it affect the run of the others ?

A: The others will not be affected and could work normally.

Q: Is the power supply safe for running ?

A: The voltage output of the power adapter is 24V. This product runs steadily and safely under the correct voltage.