


Assembly Instructions

READ THIS MANUAL

Do not use this product until you read and understand the instructions in this manual.

KEEP THIS MANUAL FOR FUTURE REFERENCE.

TIPS: Some accessories are placed under the seat base.



This manual is intended for installation and use. The pattern should be subject to the product you receive.

If you have any inquiries regarding the item, please reach out to us using the contact information provided on the left. We strive to resolve your concerns within 24 hours (excluding weekends and holidays).

WARNING:

This unit is intended for relaxation purposes only and should not be used in an attempt to treat any medical ailment.

Please note that should you have any medical condition, be under a health professional or physicians care. Or should you have a medical device fitted (eg Pacemaker etc.), you must consult a qualified medical practitioner before using this massage system.

- Do not massage any part of the body that is painful, swollen, inflamed or covered with skin irritation-consult your medical practitioner before use.
- The massage system should not be used during pregnancy.
- Do not at any time allow children to play on the chair or leave them unsupervised in the same room with the chair.
- Never operate this appliance if it has a damaged cord or plug. Contact your supplying retailer.
- Do not interfere with any part of the massage system or attempt to dismantle or repair the unit in any way.


DANGER

- Disconnect the electrical plug from the wall outlet before cleaning, moving, servicing or when not in use for an extended period of time.
- Do not use this product if it is wet, in water, around water or any liquid.
- To prevent suffocation keep plastic bags away from children.
- Plug directly into a wall outlet. Do not use an extension cord, adapter or surge protector.


PARTS AND ACCESSORIES

*** Note: Accessories are placed under the the seat base.**

Please take out the outer armrest covers, backrest ear part, assembly box and other accessories under the chair base to ensure proper installation.




A Backrest * 1pc




B Seat * 1pc

*** The backrest** you received has been vacuum-packed. Open the plastic bag, take out the backrest, let it breathe to the normal state.


R



L




C Foldable Armrest R&L * 2pcs



E Backrest Ear Part *2pcs



F M6 Wrench * 1pc



G Remote Control * 1pc




H Power Cord * 1pc



I Metal Bolt * 4pcs



ⓙ Screw M6*10 *8pcs



Ⓚ Screw M6*20 *8pcs


Please check and ensure all the things are in the package. Please feel free to contact us if something is not included. We will reply within 24 hours and try our best to solve it.

ASSEMBLY INSTRUCTIONS

CAUTION: At least two adults are required to safely assemble this recliner chair.





Other lifting attempts may risk back safety due to large and heavy part(s).




1. Carefully unpack and place parts on a clean flat surface.



2. Unzip the foldable armrests **C**.

3. Expand the iron frame of the foldable armrest **C**, fix the iron frame with the screw **J**.







- 4.** Tighten all the screws on the iron frame of the foldable armrest **C** completely as shown.




- 5.** Zip up the foldable armrests **C**.




6. Attach the metal bolts **I** on the armrest L & R with screws M6x20 **K**.






* **NOTE:** Place the wide side of the metal bolts upward for installation. If the position is incorrect, this part cannot be properly snapped into the seat's metal bolts.



7. Push the footrest to restore its initial state. Insert the metal bolts **I** of the armrests to the seat as shown below. Ensure they are correctly installed in place.





- 8.** Insert metal bolts of the backrest to the seat as shown below.
Ensure they are correctly in place.



***Tips:** First stick the Velcro between the backrest and the seat, and then insert the backrest into the seat.

- 9.** Insert metal bolts of the backrest ear parts **E** to both sides of backrest.






- 10.** Unstick the Velcro of the seat base **B** and the backrest **A**.
Connect the cables.



The method of connecting the cables.

Connect **①②** with wires of same color from the seat base.


Connect **③** with Power cord **H**
and **④** with Remote control **G**.



11. Cover the back fabric.




12. Assembly is complete.




RECLINE & MASSAGE OPERATING

A. How to recline




1. Pull the handle to lift the footrest separately.


2. Put some pressure onto the backrest to recline.



3. Have a relax.





B. How to get footrest latch down



1. The backrest will return to the upright position by moving forward.


2. Accompany the footrest to the upright position by putting pressure with your legs.



3. The recliner returns to the upright position.

C. Massage operation

INTENSITY: Change intensity (HIGH or LOW) during all modes.





We recommend that the unit be used only for a few minutes initially, to allow your body to get used to the massage sensation. Gradually increase the length of time you use the massage function, over the first few periods of use. Should you experience any adverse reactions, stop using immediately and consult your medical practitioner.

USAGE


Leave
enough space
for reclining back

45cm




The recliner should be placed 45cm away from the wall, so the reclining function can be used normally.

* **Note:** Remember to store remote control safely in the seat's side pocket when it is not in use.



*Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.

As most parts of this recliner can be moved, handle all parts with care when moving.



* Only move the recliner when it is in the 'initial position'. Never attempt to move the recliner when it is in any of the reclining position. Always use the armrests to move the recliner.


– DO NOT use the backrest or backrest ear parts to move the recliner.

PROPER USAGE




Steps to safely stand up from your Recliner Chair

1. Store the remote control **Ⓒ** safely in the seat's side pocket.
2. Plant feet firmly on the ground.
3. Evenly distribute weight on both arms of the chair.
4. Slowly stand up from upright position.




The recliner with a gentle rocking motion moves back and forth horizontally and can swivel 360° (reclining angle can not be fixed).

IMPROPER USAGE




DO NOT stand up when the footrest is in the upright position.

DO NOT stand up from your recliner chair with uneven weight.



DO NOT stand up from your Recliner chair with only one arm.



Dear Customer,

Thank you for choosing us.

For safe use, please read this manual before installation, and keep it for after use. Please feel free to email us if you have any concerns about our products. We'll reply within 24 hours.

The following are the things you need to pay attention to so that we can provide you with services when you encounter problems during the installation and use of the product:

- When the product is damaged due to courier problems, please contact our customer service in time for verification.
- We will rectify the issue as soon as possible.

We offer product explanations, installation instructions, product maintenance and maintenance methods.

If you feel satisfied with our product and service,

- Please set our store as your favorites;
- Please recommend our products to your friends;
- Please and leave us your purchase experience in our store or product page.

Feedback or reviews from you will greatly help us offer better services to players around the world.

Best regards!

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.

If you have any questions about the product, please
contact us through the contact information on the left.
We will try our best to solve your problem within 24H
(except weekends and holidays).
