

ASSEMBLY INSTRUCTIONS

Important Safety Instructions:

- For safety purpose, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into your outlet, do not force it, contact a professional electrician. Never alter the plug in any way.
- These instructions are provided for your safety. It is very important that they are read carefully and completely before assembling fixture..
- This fixture has been rated for up to (1) **60-watt maximum TYPE A bulb** (no included) or (1) **13-watt compact fluorescent light bulb** (included). To avoid the risk of fire, do not exceed the recommended wattage.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts Enclosed:

Item	Description	QTY
A	Finial	1
B	Shade	1
C	Harp	1
D	Saddle	1

Caution:

- Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation.

Warning:


- Wires and cables are all attached (further wiring is not needed from consumer). When unpacking product, be careful to not pull wires as it may result as a bad connection. Do not plug into electrical outlet until lamp is fully assembled.

Note:

Turn the power off (unplug from the wall outlet) before replacing the bulb. Make sure the bulb has sufficient time to cool down.

Assembly Instruction:

- Step1. Unpack and place all parts on a surface or floor.
- Step2. Place harp(C) onto saddle (D).
- Step3. Place shade (B) onto harp(C) and tighten finial (A).
- Step4. Screw the light bulb into the Socket.
- Step5. Assembly is completed.



Care instructions:

- Wipe with soft dry cloth only
- Always avoid the use of harsh chemicals or abrasive as they may damage to the finish.

Thank you for your purchase