


TV Stand w/ Fireplace
















Assembly Instructions

NOTE: This instruction manual contains **IMPORTANT** safety information. Please read carefully before assembling the product

List of Parts




Hardware

<p>A x 60+2</p>  <p>Ø6 x 34mm</p>	<p>B x 60+2</p>  <p>Ø15 x 10mm</p>	<p>C x 8+1</p>  <p>Ø8*30mm</p>	<p>D x 8+1</p>  <p>Ø3*12mm</p>	<p>E x 4</p>  <p></p>
<p>F x 2</p>  <p></p>	<p>G x 4</p>  <p>Ø4*22mm</p>	<p>H x 4+1</p>  <p>Ø3*16mm</p>	<p>I x 2</p>  <p></p>	<p>J x 30+2</p>  <p>Ø3.5*12mm</p>
<p>K x 12</p>  <p></p>	<p>L x 36+2</p>  <p>Ø3.5*12mm</p>	<p>M x 4</p>  <p></p>	<p>N x 2</p>  <p></p>	<p>O x 3</p>  <p></p>

STEP1

A x 4




Ø6 x 34mm

B x 4




Ø15 x 10mm




STEP2

A x 8



Ø6 x 34mm




STEP3

B x 8




Ø15 x 10mm




STEP4

A x 8



Ø6 x 34mm




STEP5

B x 8




Ø15 x 10mm




STEP6

A x 10



Ø6 x 34mm




STEP7

B x 10



Ø15 x 10mm





STEP8

L x 12




Ø3.5*12mm

O x 3




STEP9

A x 8



Ø6 x 34mm





STEP10

H x 4




l x 2




STEP11

A x 8




Ø6 x 34mm




STEP12

B x 4



Ø15 x 10mm




STEP13

B x 4



Ø15 x 10mm




STEP14

B x 8




Ø15 x 10mm

C x 4




Ø8*30mm




STEP15

A x 2



Ø6 x 34mm




STEP16

B x 2




Ø15 x 10mm




STEP17

A x 12



Ø6 x 34mm




STEP18

B x 12




Ø15 x 10mm



C x 4






Ø8*30mm









STEP19

D x 4	E x 2
	
Ø3*12mm	






STEP20

D x 4	E x 2	F x 2	G x 4
			
Ø3*12mm			Ø4*22mm





STEP21

L x 12	M x 4
	
Ø3.5*12mm	



STEP22


L x 12

Ø3.5*12mm



STEP23

K x 12

TV STAND ASSEMBLY




STEP24



J x 30




Ø3.5*12mm



STEP25




STEP26



STEP23

FIREPLACE MANTEL ASSEMBLY

K x 8




STEP24



J x 16




Ø3.5*12mm




STEP25



STEP26





FIREPLACE INSTALLATION

If you decide to install the fireplace into the mantel, carefully set the unit from the back of the mantel and center it in the opening.

Check the alignment and attach the unit to the mantel by inserting screws through the drilled holes on the trim to the mantel.

NOTE: Do not attempt to install the unit from the front of the mantel. It will not fit.