

ABSTRACT WALL  
SCULPTURE  
Assembly Instructions



# ABSTRACT WALL SCULPTURE

## Parts List


Please review all parts and hardware before disposing of any packaging.

Call Customer Service if missing hardware. Do not return to store/retailer.

Using a screw that is too long will cause damage. Before beginning assembly, separate each type of screw. Carefully study the screw diagrams below.

A


2pcs



Plastic Anchor

B

2PCS



Screw

C




Frame

### Care and Cleaning Instructions:

Before using , wipe with a clean , dry cloth.Periodically apply furniture wax to renew.Avoid rubbing or scratching the surface with rough or abrasive objects.

For replacement parts or questions, please call Customer Service. Do not return product to store. Please call manufacturer for assistance, questions or parts.

Assembly Tool Required  
No.2 Phillips Screwdriver  
Not Included





**Tool List: 1/4" drill bit, drill, tape measure and pencil.**

# ABSTRACT WALL SCULPTURE

## Assembly Instructions

**NOTE: NO DRILLED HOLE OR PLASTIC ANCHOR REQUIRED WHEN MOUNTING TO WOOD WALL. USE SCREW ONLY. WE DO NOT SUPPLY HARDWARE FOR MOUNTING ON CONCRETE WALLS.**



Step 1: Drill two 1/4" holes on wall with measurements as shown below .

Insert plastic anchors ( A ) into the holes of wall as shown.

(When doing this, you will need a hammer help you).

Using the phillips head screwdriver, install screw (B) into each of the anchors (A). Turn the screw ( B ) in until there is a gap of 3mm between the head of the screw and the wall as shown.

Install the unit onto the screw (B) and secure the bracket is resting securely on the mounting screw (B).

# Parts Replacement Form

## Customer Information

Name \_\_\_\_\_

Address \_\_\_\_\_

City/State/Zip Code \_\_\_\_\_

Phone Number \_\_\_\_\_

Please indicate where you purchased this item: Store/ Website/  
Catalog

Please indicate color/size/style number:

Style No	Parts Letter	Parts Description	Quantity Needed

Missing or damaged hardware and/ or parts will be replaced free of charge. We do not sell parts. We will provide replacement parts for only those items purchased within the last 9 months. If this product has not been purchased from our retail affiliates (within 9 months), we are under no obligation to provide parts or replacements merchandise. Parts will not be available for items arriving fully assembled.

Please contact us if you have product issues with your purchase. Please ask for a customer service representative for issues involving damages or replacement parts. Please ask for a technical assistance representative for any issues with product assembly and product construction.

Please contact the retailer that you purchased from for returns.