


110V


Installation & Operating Instructions for the
Owner's Installation ,Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

4LTS LINEAR CHANDELIER



PACKAGE CONTENTS




PART	DESCRIPTION	QTY.
A	Canopy	1
B	Mounting bracket	1
C	Outlet box screw	2
D	Large hex nut	2
E	Lock washer	2
F	Safety cable	1
G	Small hex nut	1
H	Lock ball	1
I	Swivel	1

PART	DESCRIPTION	QTY.
J	6 In. rod	4
K	12 In. rod	4
L	Lamp body	1
M	Shade-1	4
N	Shade-2	4
O	Socket collar	4
P	Wall anchor	1
Q	Flat washer	1
R	Screw	1
S	Steel plate	1

HARDWARE CONTENTS

AA



Wire
Connector
Qty: 3

! SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

! WARNING

- IMPORTANT: NEVER attempt any work without shutting off the electricity.
- Place the main power switch in the "OFF" position and unscrew the fuse(s), or switch "OFF" the circuit breaker switch(es), that control the power to the fixture or room you are working in.
- Place the wall switch in the "OFF" position. If the fixture to be replaced has a switch or pull chain, place it in the "OFF" position.
- Do not use bulbs with wattage greater than specified on this fixture.
- California Prop. 65: This lighting fixture contains chemicals known to the state of California to cause cancer, birth defects, and/or other reproductive harm. Wash hands after use.

CAUTION

- If you have any doubts about how to install this lighting fixture, or if the fixture fails to operate completely, please contact a licensed electrical contractor.
- All parts must be used as indicated in these instructions. Do not substitute any parts, leave parts out, or use any parts that are worn out or broken. Failure to obey this instruction could invalidate ETL listing and/or C.S.A. certification of this fixture.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated assembly time: 30 minutes to 1 hour

Tools Required for Assembly (not included): Phillips screwdriver, wire strippers, electrical tape, ladder, safety glasses.

ASSEMBLY INSTRUCTIONS


1. 6 In. rod (J) 12 In. rod (K) Lamp body (L)

Note: Choose desired hanging length for the lamp body. Assemble the rods to the desired length. Pass the fixture wire through the rod assembly. Attach the rod assembly to the lamp body. Hand-tighten until snug.



2. Mounting bracket (B) Outlet box screw (C)

Note: Secure the mounting bracket to the outlet box (not included) with outlet box screws. Tighten until snug.




3. Large hex nut (D) Lock washer (E)

Safety cable (F) Canopy (A) Steel plate (S)

Swivel (I)


Note: Remove the large hex nut, the lock washer, the safety cable, the canopy, the steel plate and the swivel from the canopy assembly.



ASSEMBLY INSTRUCTIONS


4. Swivel (I) 6 In. rod (J)

Note: Thread the swivel to the uppermost rod.
Hand-tighten until snug.



5. Large hex nut (D) Lock washer (E) Lanyard (F) Canopy (A) Steel plate (S) Swivel (I)


Note: Place the previously removed steel plate, the canopy, the safety cable and the lock washer over the swivel.
Secure with the previously removed large hex nut.



ASSEMBLY INSTRUCTIONS

6. Wall anchor (P)


Not e: Use a screwdriver to insert the wall anchor. Do not “push” or drive the wall anchors into the ceiling, it is designed to bore into the ceiling like a drill bit. Slowly turn the wall anchor clockwise while applying pressure until the flange just touches the ceiling.



7. Wall anchor (P) Safety cable (F)

Flat washer (Q) Screw (R)

Not e: Insert the screw into the center hole of steel washer and the eyelet grommet. Using a screwdriver, proceed to secure the safety cable with the screw in the eyelet grommet into the wall anchor.



ASSEMBLY INSTRUCTIONS

8. Wire connection guide:
Use the wire connectors to connect the wires.

Ground wire:

- For installation in the United States: Wrap ground wire from outlet box around ground screw preassembled on mounting bracket (B) no less than 2 in. from wire end. Tighten ground screw. If fixture is supplied with a ground wire, connect to outlet ground wire with a wire connector (AA).
- For installation in Canada: If fixture is supplied with ground wire, wrap ground wire around ground screw on mounting bracket (B). Tighten ground screw. Connect fixture ground wire to outlet ground wire with the wire connector (AA).

Supply wires:

- Connect the Neutral (White) supply wire from the outlet box to the Neutral fixture wire (White or Parallel Cord "D" shaped and ribbed).
- Connect the Hot (Black) supply wire from the outlet box to the Hot fixture wire (Black or Parallel Cord round and smooth).

NOTE:

Fixture wires will either be:

- Black and White.
- Parallel Cord SPT-1 lamp wire with one round smooth wire and one "D" shaped and ribbed wire.

AA BARE COPPER,
OR GREEN
GROUND
FIXTURE
WIRE

BARE COPPER,
OR GREEN
GROUND
SUPPLY WIRE

BLACK SUPPLY
WIRE

BLACK FIXTURE
WIRE

WHITE SUPPLY
WIRE

WHITE FIXTURE
WIRE

BLACK SUPPLY
WIRE

OR PARALLEL
FIXTURE CORD
(ROUND AND
SMOOTH)

WHITE SUPPLY
WIRE

PARALLEL FIXTURE
CORD ("D" SHAPED
AND RIBBED)



Hardware Used

AA Wire Connector




x 3

9. Mounting bracket (B) Canopy (A)

Small hex nut (G) Lock ball (H)

Note: Re-attach the canopy to the mounting bracket.
Secure with the small hex nut.
Then, attach the lock ball over the canopy.




ASSEMBLY INSTRUCTIONS

10. Lamp body (L) Shade-1 (M)

Shade-2 (N) Socket collar (O)


Note: Remove the socket collar from the socket of the lamp body.
Then, place the shade-1 and shade-2 over the socket of the lamp body as shown.
Secure by threading the socket collar onto the socket. Hand-tighten until snug.



11. Install the correct bulbs (not included) referring to fixture markings and/or labels for maximum wattage.



NOTE: Use four 60W maximum Candelabra base (E12) type "B" incandescent lamp or 9W maximum Candelabra base (E12) self-ballasted LED bulbs (sold separately).



CARE AND MAINTENANCE

- . Always be certain that electric current is turned off before cleaning this item.
- . Use a soft, moist cloth with mild non-abrasive soap to clean fixture. Never use glass cleaner on fixture, as it will damage the metal finish.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Fixture does not light.	1. Fixture may be wired incorrectly.	1. Check wiring.
	2. Worn or broken bulb.	2. Replace bulb.