



1




Turn the tent upside down and hold the edges firmly with both hands.

2



Twist one side of the tent inward with one hand until it overlaps.

3



Hold the edges of the twisted and overlapped tent.

4



Apply more force and repeat Step 2 to further fold the tent.

5



Adjust and tidy the tent into a compact shape.

6



Place the folded tent into the carrying bag.



TINY LAND



Scan the QR code above to view the detailed instruction video.