

**SLAT BACK DINING CHAIR WITH
CUSHION SEAT**

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS :

1. Remove hardware from plastic bag and sort by size.
2. Please check to see that all hardware and part are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



Warning !



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION:

A		CHAIR BACK	1PC
B		FRONT LEG FRAME	1PC
C		SIDE RAIL	2PCS
D		CUSHION SEAT	1PC


HARDWARE IDENTIFICATION:

1		ALLEN WRENCH	1PC
2		BOLT	6PCS
3		LOCK WASHER	6PCS
4		FLAT WASHER	6PCS
5		PAN HEAD SCREW	4PCS


NOTE : QUANTITIES SHOWN ARE FOR ONE CHAIR.
NOTE : PHILLIPS HEAD SCREW DRIVER IS REQUIRED IN THE ASSEMBLY PROCESS. HOWEVER, MANUFACTURER DOES NOT PROVIDE THIS ITEM.

ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2



STEP 3



STEP 4

