EASY GROW PLANTER

WARRANTY

WHAT IS COVERED

We warrant the product to be free from defects in material or workmanship for a period of one year from the date of original retail purchase. The word "defects" is defined as imperfections that impair the use of the product. Defects resulting from misuse, abuse or customer negligence will void this warranty.


WHAT IS NOT COVERED


This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. This warranty does not cover defects due to alteration or accidents. This warranty does not cover scratches, scuffs or other cosmetic damages that may result from normal use of the product.


CARE INSTRUCTIONS

Thank you for choosing EASY GROW PLANTER. With a little care and maintainance, this EASY GROW PLANTER will provide you with comfort and enjoyment for many years to come!

- To clean panels, use clean water on a damp cloth. DO NOT pressure wash, this will damage the finish.
- When assembling EASY GROW PLANTER, please handle all the panels and/or hardware with care to avoid any possibilities of damages and/or injuries.
- Cover during harsh weather to keep it from weathering.
- It is highly recommended that you treat this EASY GROW PLANTER with a weatherproof coating of stain once a year, to increase life expectancy and maintain the look.







7 LEG CAPS

X 4PCS

