















 Ax1	 Bx1	 Cx1	 Dx3
 Ex1	 Fx1	 Gx1	 Hx3
 Ix7 M6x35	 Jx19 M6x13	 Kx13	 Lx1
SPARE(Ersatzteile)			
 Ix1 M6x35	 Jx1 M6x13	 Kx1	


### Step1 (SCHRITT1)




### Step2 (SCHRITT2)




### Step3 (SCHRITT3)



### Step4 (SCHRITT4)



### Step5 (SCHRITT5)



### Step6 (SCHRITT6)

