


CARE & MAINTENANCE

1. Wipe a clean, lint free cloth.
2. Do not use ammoniated detergents, metal or polish or other abrasive cleaning agents.
3. Avoid Spills, wipe up immediately with a dry, clean, lint free cloth.
4. Do not expose to harsh or direct sunlight.
5. Please make sure that you have all parts indicated before you begin assembly of this item.
6. This item should be assembled on a soft surface to prevent scratching the finish during assembly.




happimess™

Kitchen Paper Roll Holder

ASSEMBLY INSTRUCTIONS



Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Paper HOLDER ROD		1
B	Paper HOLDER BASE		1
C	SCREW		1
D	ALLEN KEY		1

