


Assembly Instruction of (Cabinet)



Scan QR Code for Assembly Video



Scan this QR code to watch the step-by-step assembly video for your 3-in-1 Compact Vanity. Follow the video instructions to complete installation quickly and correctly. If you cannot scan the code, please copy and open the YouTube link below in your browser:
https://youtu.be/LmAn5iHC_Zo

Keep small parts out of reach of children !


Contact Us

We're here to help you.

Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.

Warm Tips


1. Carefully read these instructions and keep them for future reference.
2. Check the parts list and confirm everything's there before starting assembly.
3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.



EN_QUICKFIT: Tighten the Quickfit until the head is flush with the panel. Do not over-tighten or under-tighten.

FR_RACCORD RAPIDE: Faites serrer le raccord rapide jusqu'à ce que l'épaule soit parfaitement encastré dans le panneau. Il ne faut ni trop serrer ni insuffisamment serrer.


ES_QUICKFIT: Apriete quickfit hasta que el hombro se descargue con el panel. NO lo sobreapriete ni lo apriete poco.



EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.

FR_SERRURE BATTEUSE: Avant d'insérer la serrure batteuse, veillez à la bonne orientation avant d'insérer le raccord rapide.

ES_CIERRE DE LA CÁMARA: Cuando instale el cierre de la cámara, asegúrese de que la posición de inicio es correcta antes de que inserte el quickfit conector.



EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.


The cam lock must be inserted before the Quickfit.

FR_Lorsque les deux panneaux sont assemblés, la tête du raccord rapide doit reposer au centre de la serrure batteuse.

Il faut insérer la serrure batteuse avant le raccord rapide.

ES_El cabezal del quickfit debe estar en el centro del cierre de la cámara cuando se unan los dos paneles.




Se debe insertar el cierre de la cámara antes que el quickfit.



EN_Turn cam lock clockwise to tighten.


FR_Faites tourner la serrure batteuse dans le sens des aiguilles d'une montre pour la resserrer.

ES_Gire el cierre de la cámara en sentido horario para apretarlo.





We recommend using hand tools for assembly.

If an electric screwdriver is used, reduce power and torque to avoid damage to the product.



Install the Anti-Tip Device


Using the anti-top device can reduce the risk of tipping over, but can not eliminate it.



EN_ It may be necessary to adjust the hinges so that the doors align. Use the instructions below as a guide.

FR_ Il est parfois nécessaire d'ajuster les charnières pour un meilleur alignement des portes. Servez-vous des instructions ci-dessous comme guide.


ES_ Puede que sea necesario ajustar los quicios de forma que se alineen las puertas. Use las instrucciones que aparecen debajo como guía.



EN_ To adjust the door vertically loosen the screw as shown and move up and down as needed.

FR_ Si vous souhaitez régler la porte **verticalement**, desserrez la vis comme indiqué et déplacez la porte de haut en bas selon les besoins.


ES_ Para ajustar la puerta **verticalmente** afloje el tornillo tal y como se muestra y muévelo hacia arriba o hacia abajo según sea necesario.



EN_ To adjust the gap from the door to the main frame turn the screw clockwise or anti-clockwise as needed.

FR_ Si vous souhaitez ajuster l'**écart** entre la porte et le cadre principal, tournez la vis dans le sens des aiguilles d'une montre ou dans le sens inverse, si nécessaire.


ES_ Para ajustar el **espacio** desde la puerta al marco principal, gire el tornillo en sentido horario o antihorario, según se necesite.



EN_ To adjust the door laterally adjust the screw as shown by turning clockwise or anti-clockwise.

FR_ Si vous souhaitez ajuster la porte **latéralement**, ajustez la vis comme indiqué en tournant dans le sens des aiguilles d'une montre ou dans le sens inverse des aiguilles d'une montre.

ES_ Para ajustar la puerta **lateralmente** ajuste el tornillo tal y como se muestra girándolo en sentido horario y antihorario.



EN_ Please fix other screws

FR_ Merci de serrer les autres vis.

ES_ Fije los demás tornillos



[EN]

Warning: Please read instructions fully before starting assembly. Check that you have all components and tools listed on the following pages.

Warning: Please place all parts on a flat surface. Place a soft blanket or similar underneath to protect against scratches or stains. Avoid dragging or sliding parts across the floor.

Warning: Regularly check all fittings and fastenings to ensure they are secure and to prevent accidents. If any parts are missing, broken, damaged, or worn, discontinue use of the product until repairs have been made using factory authorized parts.

Warning: Do not allow children to climb on the furniture as this may result in tipping and serious personal injury. Assemble the furniture away from the reach of children.

Warning: Do not place furniture close to fire sources or high-temperature objects to avoid the risk of fire.

Warning: Clean furniture with a damp cloth or alcohol, avoid using cleaning agents containing corrosive chemicals.

Warning: This product is equipped with an anti-tip device. Please be sure to install this device to prevent unnecessary injuries caused by tipping.

[FR]

Avertissement : Veuillez lire entièrement les instructions avant de commencer l'assemblage. Vérifiez que vous disposez de tous les composants et outils répertoriés sur les pages.

Avertissement : Veuillez placer toutes les pièces sur une surface plane. Placez une couverture douce ou similaire en dessous pour les protéger des rayures ou des taches. Évitez de faire glisser les composants sur le sol.

Avertissement : Vérifiez régulièrement tous les raccords et fixations pour vous assurer qu'ils sont bien fixés et pour éviter les accidents. Si des pièces manquent, sont cassées, endommagées ou usées, cessez d'utiliser le produit jusqu'à ce que des réparations aient été effectuées à l'aide de pièces autorisées par l'usine.

Avertissement : Ne laissez pas les enfants grimper sur les meubles car cela pourrait entraîner un basculement et des blessures graves. Assemblez les meubles hors de portée des enfants.

Avertissement : Ne placez pas les meubles à proximité de sources de feu ou d'objets à haute température pour éviter tout risque d'incendie.

Avertissement : Nettoyez les meubles avec un chiffon humide ou de l'alcool, évitez d'utiliser des produits de nettoyage contenant des produits chimiques corrosifs.

Avertissement : Ce produit est équipé d'un dispositif anti-basculement. Assurez-vous d'installer ce dispositif pour éviter les blessures inutiles causées par un basculement.

[ES]

Advertencia: Lea las instrucciones completamente antes de comenzar el montaje. Compruebe que tiene todos los componentes y herramientas que se enumeran en las páginas.

Advertencia: Coloque todas las piezas sobre una superficie plana. Coloque una manta suave o algo similar debajo para protegerlas de rayones o manchas. Evite arrastrar o deslizar los componentes por el piso.


Advertencia: Verifique regularmente todos los accesorios y fijaciones para asegurarse de que estén seguros y evitar accidentes. Si falta alguna pieza, está rota, dañada o desgastada, deje de usar el producto hasta que se hayan realizado las reparaciones con piezas autorizadas de fábrica.

Advertencia: No permita que los niños se suban a los muebles, ya que esto puede provocar que se vuelquen y lesiones personales graves. Monte los muebles fuera del alcance de los niños.

Advertencia: No coloque los muebles cerca de fuentes de fuego u objetos de alta temperatura para evitar el riesgo de incendio.

Advertencia: Limpie los muebles con un paño húmedo o alcohol, evite usar agentes de limpieza que contengan químicos corrosivos.



























Advertencia: Este producto está equipado con un dispositivo antivuelco. Asegúrese de instalar este dispositivo para evitar lesiones innecesarias causadas por vuelcos.

















⚠ Caution

Please ensure all parts are included. Most board components are labeled or stamped on the raw edges. If you find any damaged or missing parts, feel free to contact us for a free replacement.

Parts List


				
❶ 1PC	❷ 1PC	❸ 1PC	❹ 1PC	❺ 1PC
				
❻ 1PC	❼ 1PC	❽ 1PC	❾ 1PC	❿ 1PC
				
⓫ 1PC	⓬ 1PC	⓭ 1PC	⓮ 1PC	⓯ 1PC
				
⓰ 1PC	⓱ 1PC	⓲ 1PC	⓳ 1PC	⓴ 1PC
				
⓵ 1PC	⓶ 1PC	⓷ 1PC	⓸ 1PC	⓹ 1PC
				
⓺ 1PC	⓻ 1PC	⓼ 1PC	⓽ 1PC	⓾ 1PC

Hardware List

A	B	C	D	E	F
					
M6x35mm	Ø15x9mm	M3.5x14mm	M3.5x25mm	4mm	M5x40mm
42PCS	42PCS	38PCS	5PCS	1PC	4PCS
G	H	I	J	K	M
					
Ø8x30mm	M4x10mm		M4x35mm		Ø5x17mm
10PCS	2PCS	2PCS	9PCS	2PCS	6PCS
N	O	P	Q	R	S
					
		Hyaline Rubber Ø15x2mm		M4x12mm	
6PCS	2PCS	4PCS	1PC	1PC	1PC
T	U				
					
Ø6x30mm	colored				
1PC	1PC				



STEP 1

Ensure that your floor is properly protected.




A	X22
	
M6x35mm	

STEP 2




Press down the plastic latch to separate the slide into two sections: I1 and I2.



I	X2
	
I1	

C	X4
	
M3.5x14mm	


STEP 3



G	X1
	
Ø8x30mm	

F	X2
	
M5x40mm	


STEP 4



K	X2
	

C	X8
	
M3.5x14mm	



STEP 5



G	X1
	
Ø8x30mm	

F	X2
	
M5x40mm	



STEP 6



G	X1
	
Ø8x30mm	



B	X5
	
Ø15x9mm	

STEP 7



B	X6
	
Ø15x9mm	


STEP 8



G	X1
	
Ø8x30mm	

B	X11
	
Ø15x9mm	


STEP 9






C	x4
	
M3.5x14mm	

STEP 10




10-1



10-2




Note: The side with hex screw holes faces right.




STEP 11

Please tighten the screw
clockwise to adjust the strength
of the randomly stopped accessory.




STEP 12




P	x4
colored	
	
Ø15x2mm	


M	x8
	
Ø5x17mm	

STEP 13




10	x1
	


STEP 14



STEP 15




STEP 16




G	X2
	
Ø8x30mm	


STEP 17




STEP 18




STEP 19




STEP 20




CAUTION !
Incorrect Operation




DO IT THIS WAY



Push the ball bearings to its extreme end.




Insert Slide I2 into Slide I1.





Insert Slide I2 into I1 slowly and parallelly until you hear the plastic latch click into place.

STEP 21



R	x1	S	x1
			
M4x12mm		150x20mm	

STEP 22




T	X1
	
Ø6x30mm	

J	X1
	
M4x35mm	


STEP 23

Ensure that your floor is properly protected.




A	X8
	
M6x35mm	

STEP 24



Step 24 and 25 will be completed on the same board # 20.




Push the slide rail forward, and fix the first screw at the rear end of the slide rail(BACK).

O	X1

C	X1
M3.5x14mm	


STEP 25




Then push the slide rail back, fix the second and third screws at the front end of the slide rail.

C	X2
M3.5x14mm	

STEP 26



Step 26 and 27 will be completed on the same board # 21.




Push the slide rail forward, and fix the first screw at the rear end of the slide rail(BACK).

O	X1

C	X1
M3.5x14mm	



STEP 27



Then push the slide rail back, fix the second and third screws at the front end of the slide rail.



C	X2
M3.5x14mm	

STEP 28




B	X4
	
Ø15x9mm	

STEP 29




B	X4
	
Ø15x9mm	


STEP30



STEP31




STEP32




STEP33





Assembly Instruction of (Cabinet Drawer)



STEP 34




STEP 35




A	X4
	
M6x35mm	

B	X4
	
Ø15x9mm	

STEP36



STEP 37




U	X1	H	X2
			
		M4x10mm	

STEP 38


LED Light 3-Level Brightness Adjustment

1, Tap the touch power switch to cycle through different brightness modes.

2, Press and hold the switch for stepless brightness adjustment from 0% to 100%.



Finished!



Congratulations, you have made it through the assembly process! We're almost there! ☆

Please perform following checks to ensure assembly is properly done.

Move your product carefully, with 2 people lifting it to the preferred location. Clean the product with a dry cloth. You are all set!

Enjoy your fresh and updated living space thanks to the addition of your new product!