


















ASSEMBLY INSTRUCTIONS



6 DRAWER DRESSER



A		Ø7x50mm	08	Q		06
B		Ø6x40mm	08	R		05
C		Ø4x30mm	38	S		06
D		Ø7x50mm	01	T		06
E		Ø5x12mm	30	U		01
F		Ø8x20mm	08	V		12
G		Ø15x11mm	30	X		01
H		Ø8x30mm	58			
I		Ø4x40mm	13			
J		Ø4x20mm	20			
K		Ø4,5x60mm	18			
L		Ø6x7mm	12			
M		Ø3,5x14mm	24			
N		Ø6x10mm	12			
O			12			
P		Ø4x50mm	02			

REPLACEMENT PARTS

Please do not contact the company purchased from as we can help you faster.
Order replacement parts and hardware at "www.boltonfurniture.com".



Slotted Tool

Phillips Tool




Tools Required





Hammer


* These tools are not supplied by the manufacturer


01






F	 Ø8x20mm	08
B	 Ø6x40mm	08
H	 Ø8x30mm	44



02




J	 Ø4x20mm	20
---	---	----



03





S	 330mm	03
T	 330mm	03
N	 Ø6x10mm	12


04




H	 Ø8x30mm	10
O		12


05

C	 Ø4x30mm	04
V	 Ø4x25mm	04





06




E	 Ø5x12mm	30
---	--	----

07




D		Ø7x50mm	01
---	--	---------	----


08




G		Ø15x11mm	06
V		Ø4x25mm	04


09




V		04
I		09



10




C		04
---	---	----

11





U		01
A	 Ø7x50mm	08

12





H	 Ø8x30mm	04
---	---	----


13




14







15




R		05
27x23mm		

16




S	 330mm	03
T	 330mm	03
L	 Ø6x7mm	12




17




G	 Ø15x11mm	24
C	 Ø4x30mm	24



18




S	 330mm	06
T	 330mm	06
M	 Ø3,5x14mm	24


19



Q		06
C	 Ø4x30mm	06

20



I	 Ø4x40mm	04
---	--	----








21

WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.





This is a permanent label. Do not remove!




22



Secure to Stud behind Wallboard.



Secure to Stud behind Wallboard!

X	Hardware of WallBoard			
	 Ø4x30mm	02		02
	 Ø4x16mm	02	 140mm	01