

INSTALLATION INSTRUCTIONS

IMPORTANT

Before assembling your fixture, please make sure that you carefully read through these instruction sheets. Consider having your fixture installed by a qualified licensed electrician.



NOTE: The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care, are factors that can't be built into any product. These factors must be supplied by the person(s) caring for and operating the fixture.

GENERAL INFORMATION

All electrical connections must be in accordance with all ordinances, Local and National Electrical Codes. These fixtures are intended for mounting to a standard 4" x 2 1/2" metal octagon outlet box. The box must be directly supported by the building structure and U.L. Recognized.

STEP BY STEP INSTRUCTIONS

Before starting your installation disconnect the Power by turning off the Circuit Breaker or by removing the fuse at the fuse box. Just turning the light off at the light switch is not sufficient to prevent electrical shock.



APPLICATION

Wall Fixture

WHAT WE PROVIDE

- Mounting Hardware
- Crossbar Plate
- 1 x Frosted glass shade


WHAT YOU NEED

- Screwdriver
- Wire Cutters
- Wiring Supplies as Specified by Electrical Code
- 1 x 75W A19 E26

MOUNT CROSSBAR PLATE AND WIRE CONNECTIONS

1

If there is an existing fixture remove it. Expose the supply wire from the J-box. Mount the crossbar to the J-box with the supplied screws. Connect the black supply wire to the black fixture wire. Secure with the supplied wire nuts. Connect the white supply wires to the white fixture wire. Secure with the supplied wire nuts. Either wrap the green wire around one of the protruding screws or connect it to the supply ground wire. Secure all wire with electrical tape (not supplied). Tuck all wires carefully into the J-Box.



2


MOUNT FIXTURE TO CROSSBAR AND INSERT THE BULB

Position the fixture plate over the crossbar.

Align the centre holes of the plate and secure with the supplied screw knobs.

Insert the bulb. MAXIMUM WATTAGE 75W.

DO NOT EXCEED THE WATTAGE AS STATED
ON THE WARNING LABEL AND IN THE INSTRUCTION
SHEETS




3

SECURE THE GLASS SHADE AND METAL FRAME

Position the glass shade and metal frame over the
fixture plate. Align the holes of the plate and
secure with the supplied screws.

* This fixture is wet location rated. In order to ensure
that moisture does not enter the outlet box and cause
a short circuit, clear caulking should be used to seal the
space between the fixture mounting bracket and the
wall. Ensure that a space is left at the bottom to allow
for the escape of moisture. It is recommended that
Indoor/Outdoor Silicon Sealant be used for that purpose**



4

RESTORE THE ELECTRICITY AND CHECK THE OPERATION OF YOUR NEW ACCESS LIGHTING FIXTURE

