


Assembly Instruction

Bar stool



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Thank you for choosing our product.

We are committed to delivering exceptional customer service to ensure your satisfaction.

Parts Confirmation:

- Upon unpacking, verify that all parts listed in the manual are present.
- If any parts are missing or incorrect, please notify us immediately. We will promptly arrange replacements, or other solutions to ensure the issue is resolved.


Assembly Guidance:



- Carefully review the instruction manual before assembly.
- The manual has detailed steps, but it might not cover all situations. If you need help or have questions, contact us and we'll respond quickly.

Shipping Note


- If you purchased multiple packs, kindly note that the items in your order might come in separate packages. We appreciate your patience during delivery.

Parts List

Number	Name	Part	Qty
1	Back		X1PC
2	Seat		X1PC
3	Backrest outer ring		X1PC
4	Leg-L		X1PC
5	Leg-R		X1PC
6	Crossbar		X2PC
7	Footrest		X1PC



Number	Hardware	Part	Qty
H	M6*16mm		X4+1EXT
I	M6*40mm		X2+1EXT
J	M6*16mm		X2+1EXT
K	M6*30mm		X6+1EXT
L	Allen Wrench M4		X1PC
M	Allen Wrench M6		X1PC
N	Decorative cover		X2+1EXT

01





02

Tighten the four screws to a depth of 50%.





03

Tighten the four screws to a depth of 50%.





04


Tighten the four screws to a depth of 50%.



05




06



Finally tighten all screws to a depth of 100%.

Assembly complete

**Note:**

The hind legs has an adjustable foot leveler to help level your chair. Rotate it to ensure the chair is flat on the floor !

Safety Guidelines

-  Periodically inspect and tighten bolts to prevent loosening during use.
-  Ensure all hardware remains securely fastened before using.
-  Do not allow children to climb or jump on the stool.

Care Instructions

-  Avoid placing hot items, direct sunlight, or harsh chemicals on the furniture
-  Wipe dust with a soft, clean, lint-free cloth.
-  Use adjustable foot levelers on each leg to stabilize the chair on uneven floors.
-  Note: Indoor Use Only: Do not place the furniture outdoors or in damp environments.

Thank you for your purchase