


Entertainment Center

Assembly Instructions - Please keep for future reference



Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING
In order to help prevent overturning –
please follow these instructions












To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases, more fittings may be supplied than required.

 Cam Bolt x 62	 Dowel x 54	 Cam lock x 62	 340mm Drawer slide x 4
 3*12mm Screw x 18	 Oblique foot x 4	 Iron foot x 2	 3.5*14mm Screw x 26
 Shelf support pin x 9	 3.5*14mm Straght bend x 4set	 3*12mm/D5/Drawer pull x 4set	 4*25mm Screw x 9
 Allen key x 1	 4*20mm Screw x 2SET	 4*35mm Screw x 2SET	 3.5*14mm Backboard x 20SET

Tools required



Phillips screwdriver
(medium & large)


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.




You should feel a click when the camlock is locked in place.

The joint is now secure.

4




Assembly Instructions



Assembly Instructions

Step 1




D




340mm Drawer slide x 4

Step 2




A



Cam Bolt x 8

D1



340mm Drawer slide x 2


E




3*12mm Screw x 4

Assembly Instructions

Step 3



(A)



Cam Bolt x 8

(D1)




340mm Drawer slide x 2

(E)



3*12mm Screw x 4

Step 4



(B)



Dowel x 8


(C)



Cam lock x 8

Assembly Instructions

Step 5



(B)




Dowel x 8

(C)




Cam lock x 8

Step 6




(F)



Oblique foot x 4

(G)



Iron foot x 2



(H)





3.5*14mm Screw x 24

Assembly Instructions

Step 7




Step 8






Assembly Instructions

Step 9



Step 10



(B)



Dowel x 10


(C)




Cam lock x 10

Assembly Instructions

Step 11




(I)




Shelf support pin x 8

Step 12




(J)



3.5*14mm Straight bend x 4


(K)




3*12mm/D5/Drawer pull x 2

Assembly Instructions

Step 13




Step 14




Assembly Instructions

Step 15

x2



D2



340mm Drawer slide x 4


E




3*12mm Screw x 8

Step 16


x2



L




4*25mm Screw x 8




Assembly Instructions

Step 17




A




Cam Bolt x 8

K



3*12mm/D5/Drawer pull x 2

Step 18




C





Cam lock x 8

Assembly Instructions


Step 19



Step 20




Assembly Instructions




Assembly Instructions

Step 21




(A)



Cam Bolt x 16

Step 22



(B)



Dowel x 8


(C)




Cam lock x 8

Assembly Instructions

Step 23





Step 24





(B)  Dowel x 8	(C)  Cam lock x 8
---	--

Assembly Instructions

Step 25





Step 26




Assembly Instructions

Step 27



step 1






step 2



step 3




step 4



Entertainment Center-1

Assembly Instructions - Please keep for future reference



Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING
In order to help prevent overturning –
please follow these instructions






To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases, more fittings may be supplied than required.

 (A) Cam Bolt x 53	 (B) Dowel x 26	 (C) Cam lock x 53	 (D) 340mm Drawer slide x 6
 (E) 3*12mm Screw x 26	 (F) 4*25mm Screw x 13	 (G) 3*12mm/D5/Drawer pull x 3set	 (H) 4*35mm Anti tipping x 1set
 (I) Allen key x 1			

Tools required



Phillips screwdriver
(medium & large)


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.



You should feel a click when the camlock is locked in place.

The joint is now secure.

4




Assembly Instructions



Assembly Instructions

Step 1





D




340mm Drawer slide x 6

Step 2



A



Cam Bolt x 18

D1



340mm Drawer slide x 6


E




3*12mm Screw x 12

Assembly Instructions

Step 3



A




Cam Bolt x 1

C



Cam lock x 1

Step 4



B



Dowel x 2


C




Cam lock x 9

Assembly Instructions

Step 5



Step 6



(B)



Dowel x 2


(C)







Cam lock x 9

Assembly Instructions


Step 7



Step 8



(A)



Cam Bolt x 4

(B)



Dowel x 4


(C)




Cam lock x 4

Assembly Instructions

Step 9




(A)



Cam Bolt x 8

Step 10



(B)



Dowel x 4


(C)




Cam lock x 4

Assembly Instructions

Step 11



Step 12



(B)



Dowel x 4


(C)




Cam lock x 4


Assembly Instructions

Step 13




Step 14





(A)  Cam Bolt x 4	(B)  Dowel x 4	(C)  Cam lock x 4
--	---	--

Assembly Instructions

Step 15





Step 16



Cam Bolt x 4



Assembly Instructions

Step 17



Step 18



x3



Assembly Instructions





Step 19

x3




Step 20

x3



Assembly Instructions


Step 21



(H)



4*35Anti tipping x 1



Step 22

