


Before You Begin

Walnut finish / Two shelf levels

Read all steps before starting. Assemble on a clean, soft surface to protect the wood finish. Check the parts and hardware below before assembly.

WOOD PARTS




A Seat assembly x1 B Adjustable shelf x1 C Fixed lower shelf x1

D Leg x2 E Leg x2

Important: Legs D and E have different hole orientations. Match the labels and keep the shelf-support holes facing inward.

HARDWARE



1 Long bolts x8 2 Short bolts x4 3 Foot pads x4

4 Washers x12 5 Shelf supports x4 6 Hex key x1

ASSEMBLY NOTES

Start all bolts by hand. Leave them slightly loose until the frame and fixed shelf are aligned, then tighten evenly with hex key 6. Do not overtighten.


Keep small hardware away from children. Do not use the bench until assembly is complete and all connections are secure.

Build the Frame

Follow the part labels and hole orientation shown.

01 Attach the legs and foot pads


Place seat assembly A upside down on a soft surface. Fit legs D and E as shown. Use eight long bolts 1 and eight washers 4. Apply one foot pad 3 to the bottom of each leg.



Check that the shelf-support holes face inward before tightening. Use hex key 6; leave the bolts slightly loose for final alignment.

02 Fit the shelf supports

Turn the frame upright carefully. Insert the four shelf supports 5 into matching holes at the same height. Tap gently into place if needed; do not strike the wood directly.




All four supports must be level so shelf B sits evenly.

Complete the Bench

Install both shelves, then make the final checks.


03 Position the adjustable shelf

Lower shelf B onto all four supports 5. Make sure each corner rests securely on its support and the shelf sits level.



04 Secure the fixed lower shelf

Fit shelf C between the legs. Fasten it with four short bolts 2 and four washers 4, using hex key 6. Align the bench, then tighten all bolts evenly.



FINAL CHECK

Place on a level floor. Confirm that both shelves are secure and the bench does not wobble. Recheck the connections periodically.