



Laptop Extension Holder

SKU:STAND-PM01A/STAND-PM01M Instruction Manual

Assembly Video & Product Info

Extension + Monitor | STAND-PMO1M www.vivo-us.com/products/stand-pm01m



Extension Only | STAND-PMO1A www.vivo-us.com/products/stand-pm01a



A CAUTION! A

If you do not understand these directions, or if you have any doubts about the safety of the installation, please contact our product support team at 309-278-5303 or help@vivo-us.com for further assistance. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.



DO NOT EXCEED WEIGHT CAPACITY

FAILURE TO DO SO MAY RESULT IN SERIOUS INJURY.

We're Here for You

Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.



Give us a Call:

309-278-5303

AVG. RESOLUTION TIME (within office hrs): **5M 4S**



Chat Us:

www.vivo-us.com

AVG. RESOLUTION TIME (within office hrs): < 15 M




Email Us:

help@vivo-us.com

AVG. RESPONSE TIME (within office hrs): 1HR 8M

- 23% within < 15m
- 38% within < 30m
- 61% within < 1hr
- 83% within < 2hr
- 92% within < 3hr

Package Contents



Included Hardware & Tools




Weight Capacity:



Monitor Mounting Options






Option 2: **To Right of Laptop** Pages 8-11



Option 1 Monitor Mounted on Top of Laptop


STEP 1

Attach Laptop Holder (A) to Leg (B) using M5x6mm Screws (S-A), M5 Washers (S-B), and 3mm Allen Wrench (T-A), using the holes shown below.




STEP 2

Loosen the four Thumbscrews (A1) on Monitor Holder (A).




STEP 2 Cont'd

Slide the Monitor Holder onto the top of your laptop making sure Leg (B) is on the bottom.




Firmly re-tighten the bottom two Thumbscrew (A1).



STEP 3


Tilt your laptop screen to your desired viewing angle. Loosen the Knob (**B1**) on Leg (**B**) and extend the Leg down to your desktop. Re-tighten the Knob.






STEP 4

Insert your Monitor into the top of Monitor Holder (A).




Firmly re-tighten the upper two Thumbscrews (A1).



Option 2 Right Side Mounted Monitor


STEP 1

Attach Monitor Holder (A) to Leg (B) using M5x6mm Screws (S-A), M5 Washers (S-B), and 3mm Allen Wrench (T-A), using the holes shown below.




STEP 2

Loosen the four Thumbscrews (A1) on Monitor Holder (A).




Slide the Monitor Holder onto the right of your laptop making sure Leg **(B)** is on the bottom.




STEP 2 Cont'd


Firmly re-tighten the right two Thumbscrews (A1) onto your laptop.



STEP 3

Tilt your laptop screen to your desired viewing angle. Loosen the Knob (**B1**) on Leg (**B**) and extend the Leg down to your desktop. Re-tighten the Knob.






🕰 TIPOVER WARNING 🕰




DO NOT ANGLE LEG INWARD

LEG MUST EXTEND OUTWARD FOR STABILITY OF ASSEMBLY

STEP 4




Firmly re-tighten the remaining two Thumbscrews (A1).



Option 3 **Left Side Mounted Monitor**


STEP 1

Attach Laptop Holder (A) to Leg (B) using M5x6mm Screws (S-A), M5 Washers (S-B), and 3mm Allen Wrench (T-A), using the holes shown below.




STEP 2

Loosen the four Thumbscrews (A1) on Monitor Holder (A).




Slide the Monitor Holder left the top of your laptop making sure Leg **(B)** is on the bottom.




STEP 2 Cont'd


Firmly re-tighten the left two Thumbscrews (A1) onto your laptop.



STEP 3

Tilt your laptop screen to your desired viewing angle. Loosen the Knob (**B1**) on Leg (**B**) and extend the Leg down to your desktop. Re-tighten the Knob.






A TIPOVER WARNING A

DO NOT ANGLE LEG INWARD


LEG MUST EXTEND OUTWARD FOR STABILITY OF ASSEMBLY

STEP 4

Insert your Monitor into the top of Monitor Holder (A).



Firmly re-tighten the remaining two Thumbscrews (A1).





Need Help? Get In Touch

Monday-Friday from 7:00am-7:00pm CST



help@vivo-us.com



www.vivo-us.com
Chat live with an agent!



309-278-5303

