


ASSEMBLY INSTRUCTIONS



Contents:

- 4 - Leg Assemblies
- 1 - White Table Cover
- 1 - Doubled Sided Grid Deck
- 4 - Leg Washers
- 4 - Leg Wing Nuts
- 4 - Leg Washers

1. Please inspect parts for damage during shipping and for any missing items. If you suspect that there may be damage or a shortage, contact us and we will send replacement parts if needed. At this time, visualize how the components fit together and make sure that you have everything identified.
2. This product is easiest assembled upside down. Remove building surface deck(s) by pushing them from the underside only. Damage can occur if you try to pry the decks out with fingernails or a tool like a screwdriver from the top. All table legs are interchangeable. Choose a leg and place into position in the frame corner. The bolt fits through the corner block from the outside of the table. Place a washer on the bolt and start a wing nut from the inside of the table by hand per the above diagram. Tighten until fairly snug using your hand only. Repeat this procedure for the other 3 legs. Overtightening the wing nut with a tool can cause permanent damage.
3. Take the loosely assembled table and place it right side up on a hard flat surface. Push gently on table frame so that all four legs are making contact with the floor and the table frame is level. Fully tighten by hand all 4 Wing Nuts until they are snug in place. Now gently lay the deck(s) inside the table frame and assembly is complete.

If you have problems with assembly, please contact us. This product is finished with an environmentally friendly waterbased acrylic. It is totally non toxic and made in the USA. There may be an odor when taken out of the box. It will dissipate more rapidly with warmer temperature and air movement. The wood and plastic surfaces may be cleaned with any non-abrasive cleaner that does not contain ammonia.